

JAVELIN AIRSOFT WORKS M24 ASSEMBLY INSTRUCTIONS

- 1) ATTACH UPPER BARREL ASSEMBLY TO LOWER RECEIVER
- 2) INSERT LONG SCREW INTO SCREW HOLE TO THE REAR OF TRIGGER AND TIGHTEN
- 3) INSERT SHORT SCREW INTO SCREW HOLE TO THE REAR OF THE MAGAZINE WELL AND TIGHTEN

UNIVERSO SNIPER
AIRSOFT



LONG SCREW

SHORT SCREW