

English User Manual

中文版 日本語





www.acetk.com

Safety and Precautions



To avoid the risk of high voltage circuit electrical shock, do not disassemble Brighter C



Do not look into the gun barrel to avoid accidental discharge of BB.



Charge the battery at least every 2 months when the tracer is not used to avoid completely discharging the battery. Defect of completely discharging the battery is not covered by warranty.



With the lid tighten, Brighter C is with IP64 rating, dust and splash proof, suitable for outdoor use.



Suitable for green tracer BBs.



- *All the specifications and contents in this manual are subject to change without notice.
- *All the specifications and contents are only for reference, please make the object as the standard.

Contents











Brighter C

User Manual x1

Micro USB to Type A cable for charging x1

L shape Allen key for converter x1

Converter M14(-) to M11+ x1

Features

- Brighter C is compact and lightweight tracer, suitable for water BB and tracer BB
- Patented design without switch, power on by shaking, enter sleep mode while not in use.
- Can be used as tracer module, and put into silencer.

Instructions

Charging the battery

- Rotate the lid counter clock wise to remove, use Mico USB cable to recharge. (Figure 1)
- Charge at least 3 hours for the first time to ensure best performance of the battery.
- Indicator breaths during charging, and goes off when charging is completed.




· Breathing light reflects progress of charging:



Green: 80% ~ 99%








• When battery is low, the LED flashes red, and Brighter turns off; please recharge Brighter as soon as possible to avoid completely discharging the battery.



Power On and Off

- Power On: Shake the Brighter, a short Beep will indicate the power is on. (Figure 1)
- Sleep mode: Brighter enters sleep mode automatically when idle for over 5 minutes, and return to standby mode when there is vibration. (Figure 2)
- Power off: Insert a pen or stick with diameter around 10mm into Brighter for 2 seconds, wait for 3 short beeps for 5 consecutive times to complete the shutdown. (Figure 3)





(Figure 1)





Installation

- Please make sure the barrel length after the screw thread is less than 10mm, or the barrel will cover the sensor of Brighter and cause malfunction. (Figure 1)
- When the sensor is covered by barrel for over 2 seconds, there will be warning of 3 Beeps every 2 seconds, please check the installation.
- When installing on pistol with M11+ screw thread, please use the converter, and tighten with the Allen key. (Figure 2)
- Please make sure Brighter and the silencer are coaxial when using it as module, miss alignment might damage Brighter. (Figure 3)
- Make sure the installation direction of Brighter is correct inside the silencer, to ensure Brighter works properly. (Figure 4)



Self-Test Mode

- Insert a pen or stick with diameter around 10mm into Brighter for 2 seconds, wait for 3 short beeps, take out the pen or stick, Brighter enters self-test mode, and indicates the result by LED and Beeps.
 - Normal: LED indicates green, with 1 second Beep.
 - Fail: LED indicates red, with 3 short Beep.





(Figure 3)

Indication Chart

LED and Beeps	Symbol	Status
1 second beep, green light	4 ₁ ₁ 1_sec ●	Power On
3 short beeps every2 second	2 sec	Barrel covered the sensor
3 short beeps 5 consecutive times	(◄ 네 - ◄ 네 -) x 5	Power off complete
Red light flash, 5 short beeps		Battery too low, force shutdown
Red breathing light	• • • •	Battery 0%~30% charged
Orange breathing light	• • • •	Battery 30%~60% charged
Green breathing light	• • • •	Battery 80%~99% charged
LED turn off after Green breathing light	→ → →	Charging complete
3 short beeps	◄ 예 ◄ 예 ◄ 예 •	3 short beeps
After self-test, green light, 1 second beep	→ ● ◀·I I sec	Self-test success
After self-test, red light, 3 short beeps		Self-test fail

Specification

- Dimension: Length 57mm, Diameter 28mm.
- Weight: 32g (without converter)
- Burst Speed: Up to 35PRS
- Certificates: FCC CE ROHS
- Battery: Li-lon, charging time 2.5 hours, last for 20,000 shots.
- BBs: Supports green tracer BBs and water BBs, not support red tracer BBs.

Warranty

- Standard One year manufacturer warranty.
- Warranty does not include damage from incorrect usage, external force, or liquid intruding inside the product.
- · Warranty does not include battery damaged by complete discharging, please recharge at least every 2 months when not in use.