www.aps-concept.com





HANDLING & INSTRUCTION MANUAL


(For All PR Model Use)

This Airsoft is not intended for unsupervised used by any persons under the age of 18 years. Always read the instructions carefully before operation









ADVANCED MAINTENANCE

repaired, and repairs should only be made by qualified personnel.

knowledge and training.

Advanced Maintenance

may make it unsafe to use.

the parts of the gun that are difficult to reach.

AND THE DISASSEMBLING THE GUN

Any advanced cleaning of the airsoft weapons should be done by an adult, ages 18 years or older, preferably someone with advanced airsoft

• To ensure the life of the airsoft gun routine inspections and maintenance should be performed.

· Advanced maintenance and disassembling of this airsoft gun includes lubricating and cleaning

• Modification of the gun mechanism may cause a gun to malfunction and tampering with a gun

Always assume and treat airsoft gun as if it were loaded and ready to fire, treat with the same respect you would a firearm.
Always handle and operate airsoft guns safely.
User should obey all laws regarding the usage and ownership of airsoft electric guns.
Misuse or careless use may cause serious injury.
Facial protection is required, you and others with you should always wear eye protection designed for airsoft use.
Always point your airsoft gun in a SAFE DIRECTION.
Always point the airsoft gun in a safe direction. NEVER POINT your airsoft gun at people or animals even if it is not loaded. Never point the airsoft gun at anything you do not intend to shoot.
Always keep your fingers away from the trigger during loading and handling. Keep your finger away from the trigger and SAFETY until you are ready to fire. After firing, return safety to the "ON" position.
Never insert items other than an airsoft BB into the magazine or gun barrel.
DO NOT re-use plastic BBs because they could possibly cause damage to you or your airsoft gun.
Your airsoft gun is designed for target shooting and is suited for both indoor and outdoor use. Always remember to place your target carefully. THINK about what you will hit if you miss the target.
Always keep the airsoft gun on "SAFE" until you are ready to shoot in a SAFE DIRECTION.
Always check to see if the airsoft gun is on "SAFE" and unloaded when getting it from another person or from storage.
Always wear eye protection designed for airsoft over your regular glasses.
Use 6mm plastic BBs only, we suggest 6mm. 20g biodegradable BBs
Never operate after drinking alcohol to avoid possible danger.
Backstops should be inspected for wear before and after each use. Discontinue use if the backstop surface shows signs of failure. Since backstop surfaces eventually fail, always place the backstop in a location that will be safe should the bac

Malfunction of motor or battery will occur if the gun is immersed in water. Stop operating the gun, remove the battery and consult our service department immediately.
Check any gun that has been dropped to ensure that its function has not been affected.

• It is possible that BBs may fire even if the magazine is removed. Direct the muzzle towards a SAFE AREA. Pull the trigger to confirm no bullets remain in the gun.

After use and before putting the airsoft gun away, always make absolutely sure that there are no BB's in the gun, the magazine is removed, the safety is "ON" and the battery is removed.
The airsoft gun and BB's should be kept in separate and secured places. Always keep the airsoft gun out of reach of children.
Do not load the airsoft gun until you are ready to fire. Do not walk, run, jump or climb when carrying a loaded airsoft gun. A loaded airsoft gun should never be carried inside a vehicle. Always keep the safety "ON", even when the

airsoft gun is unloaded.

Do not attempt to disassemble or tamper with your airsoft gun.

DO NOT MODIFY OR ALTER YOUR AIRSOFT GUN. Attempts to modify the airsoft gun in any way may make your

airsoft gun unsafe to use, cause serious injury or death and will void the warranty.

• Be courteous and mindful of those around you and cease firing if bystanders enter within firing range.

Always put the gun in a case or bag when you are carrying it, to avoid giving rise to public panic.
Select a safe place for operating the air gun. Avoid shooting in public places.
Always store this airsoft gun in a secure location, and Always store out of the reach of children.


• Always put the gun in a case or bag when you are carrying it, to avoid giving rise to public panic.

• Any change in the airsoft guns performance, such as lowered trigger force and shortened

trigger travel may indicate possible wear and should be inspected, replaced, or properly

· Unauthorized tampering of this airsoft gun will void the manufacturer's warranty.

AIMING AND FIRING SAFETY



4 FILLING THE MAGAZINE

To Load BBs

Tip Of Barrel

Clearing Jammed BBs

(where the magazine connects).

· Remove the magazine.

Cleaning the Muzzle

· Never look down the end of the barrel to see if a jam has been cleared. • Make sure the airsoft gun is on "SAFE" and pointed in a SAFE DIRECTION.

Insert the magazine and test gun in a predetermined SAFE DIRECTION.

• Never look down the end of the barrel to see if debris have been cleared. • Make sure the airsoft gun is on "SAFE" and pointed in a SAFE DIRECTION.

• Cut a strip of cotton cloth the width of the eyelet hole and rotate the cloth around the rod. • Insert the cleaning side of the rod into the barrel of the gun while slowly twisting down the muzzle.

Cotton Cloth

• Insert tapered end of the cleaning rod into the muzzle with the angle toward the breech

• CAREFULLY and slowly apply increasing pressure until you push the BB out of the breech.

Rotate The Rod

• Make sure to return the hop-up wheel to the NORMAL position.

· Maintenance is needed when BB speed becomes slow.

• Make sure to return the hop up wheel to the NORMAL position.

· Slide open the magazine cover.

· Close the magazine cover.

Insert 300 rounds of 6mm airsoft BBs.

· Insert the loaded magazine back into the airsoft gun.

WARNING

Never assume that because the airsoft gun no longer fires a BB and the loading chamber is removed, that a BB is not lodged in the barrel. Always treat the airsoft gun as though it is loaded and with the same respect you would a firearm.

• Make sure the airsoft gun is on "SAFE" (see section 8) and pointed in a SAFE DIRECTION.


damage to the airsoft gun. We recommend using .20g 6mm Biodegradable BBs.


• Use 6mm plastic BBs only in this airsoft gun. Use of any other ammunition may cause injury to you or

• While supporting the magazine, push the magazine release button and remove the magazine.

• Rotate the wind up wheel counterclockwise only to draw BBs up into the ready tube. Turn the

gear wheel until the "click click" sound changes. This should be done in a vertical position.






•Discontinue the use of a backstop if the projectile rebounds or ricochets.

8 CHECKING THE FUSE

· Maximum Voltage allowed is 12V and Ampere is 20A below. · DO NOT attempt to modify the fuse, tampering with the device may void the manufactures warranty. • Replace the fuse only if you find the fuse damaged.

Checking the Fuse



• The best position is where the BBs fly horizontally and the longest flying distance is obtained.

• Moving the lever to much towards HOP will cause bullets to clog. Firing the gun with clogged

• If the hop-up is adjusted excessively and causing the BBs to clog, stop operating the gun immediately. Return the lever to NORMAL and remove the clogged BB (see section 7). Black Ops™ will not be held responsible for any damages or accidents caused by incorrect

• The purpose of this system is to change the spin on the BB as it leaves the muzzle, allowing

• Turning excessively adversely affects the trajectory. Stop turning the dial when BBs

FIRING OPERATION

operation, disassembly, or modification of the airsoft gun.

• This airsoft gun is manufactured with an adjustable hop-up system.

BBs will damage the piston and gears.

Using the Hop-Up Mode

A CAUTION