

# MSR-001/002/003




ARES ARES




ARES ARES

# GAS CHARGING & RELOAD



REPLACE THE MAGAZINE STRIP OR RELOAD BB DIRECTLY


# SAFETY MODE




## HOP-UP ADJUSTMENT



# UNDERPROP ADJUSTMENT



## **BOLT DISASSEMBLE**









.Do not aim or shoot a person or animal as the target. .Avoid pulling the trigger carelessly.

Always put the gun in a case or bag when you carrying it.

.Always set the switch lever to the safety position. .Do not look into the gun muzzle.

.Always wear eye protective gear.

.Store the airsoft gun at the places out of reach by children.

.Do not disassemble or modify the airsoft gun.

#### DATA OF ARES MSR-001/002/003 GAS GUN

#### MSR-001/002/003



#### FEATURES

- · Highly Precision
- Up To 90% CNC 6063 Aluminum
- Structure
- Fully Upgrade And Modify
  Up To 90% Anodized Finishing
- Fully Adjustable Folding Stock Cheen Piece
- Quick Release Metal Bipod
- CNC Aluminum Outer Barrel
- User Friendly Design

#### GAS POWER:

MAGAZINE CAPACITY:

MATERIAL: HOP-UP: LENGTH:

LENGTH: WEIGHT: VELOCITY:

### 134a Standard (Optional CO2

Magazine) 23rds (6mm BB)

Bolt Action Single Nylon Fiber + Al.Alloy

Match Grade Adjustable 1020mm (1200 /1220mm)

6400g

350-380FP





## SAFETY

- . DO NOT MODIFY OR ALTER YOUR AIRSOFT GUN. Attempts to modify the airsoft gun in way may make your airsoft our unsafe to use, cause serious injury or death and will void the warranty.
- Always check to see if the airsoft our is "ON SAFE" and unloaded when getting it from another person or from
- Always keep the airsoft gun "ON SAFE" until you are ready to shoot in a SAFE DIRECTION.
- Misuse or careless use may cause serious injury.
- · Do not look into the gun muzzle.
- Do not ever point the airsoft oun at anything you do not intend to shoot.
- You and other with you should always wear shooting glasses to protect your eyes.
- If your reading or prescription glasses are not safety glasses, make sure you wear shooting glasses over your regular glasses.
- Do not put the airsoft oun away loaded. Make sure ALL of the plastic BBs are unloaded from the airsoft oun.
- Do not shoot at hard surfaces or at the surface of water. The plastic BBs may bounce off or ricochet and hit someone or something you had not intended to hit. If the plastic BBs should happen to hit a hard surface, do not reuse those plastic BBs because they could cause possible damage to your airsoft gun.
- Use 6 mm plastic BBs only.
- Always put the airsoft gun in a case or bag when you carrying it.

misuse, or by disassembly and modification of the airsoft our.

- Always store this airsoft our in a secure location and at the places out of reach by children.
- Alway treat the airsoft gun as though it is loaded and with the same respect you would a firearm. Using unauthorized repair centers or modifying the function of your airsoft gun in any way.
- may be unsafe and will void your warranty. We are not responsible for any malfunction, accidents, injuries or repair cost resulting from





Manufacturer & Brand Owner: Forever Good (Hong Kong) Ltd.











Ares Website: http://www.aresairsoft.com General Enquiries: ares@aresairsoft.com

North America: ZShot Exclusive Distributor - http://www.ZShot.com

Dealer Inquires: Sales@ZShot.com Technical Support: Support@ZShot.com

