



UNDERPROP ADJUSTMENT




BUTTSTOCK ADJUSTMENT



BOX MAGAZINE CAPACITY: 2500 RDS

BOX MAGAZINE LOADING



BATTERY INSTALLATION

DATA OF ARES M249 PARA ELECTRIC GUN

M249 PARA



FEATURES

- High Strength Nylon Fiber Housing
- Cordura Soft Box Mag
- New Design BB Feeding System
- Pressurized On / Off
- Dummy Bullet Wiring Cable
- High Strength PC Gear Box
- Aluminum Ras, Outer Barrel & Flash Hider
- Spring Release Knod
- Exchangeable Stock & Metal Bipod
- Light Weight & Compact

BATTERY:	9.6V 3300mAH Large (SC)
MAGAZINE CAPACITY:	2500rds (6mm BB)
MODE:	Full Auto / Safe
MATERIAL:	Nylon Fiber + AL.Alloy
MOTOR:	High Torque Flat Motor
HOP-UP:	Adjustable
LENGTH:	792-915mm (Stock Extend)
WEIGHT:	4000g
VELOCITY:	350-380FPS

For more detail information please visit our website

USER RESTRICTED TO 18 YEARS OF AGE OR OLDER

M249 PARA



Automatic Electric Airsoft Gun Instruction Manual • Always read through this manual before operation

SAFETY

- Do not aim or shoot a person or animal as the target.
- Avoid pulling the trigger carelessly.
- Always put the airsoft gun in a case or bag when you carrying it.
- Always set the switch lever to the safety position.
- Do not look into the gun muzzle.
- Always wear eye protective gear.
- Store the airsoft gun at the places out of reach by children.
- Do not disassemble or modify the airsoft gun.
- Misuse or careless use may cause serious injury.
- Never point or shoot at people or animals.
- Disassembling or modifying the airsoft gun may generate danger.
- Do not ever point the airsoft gun at anything you do not intend to shoot.
- Always treat the airsoft gun as though it is loaded and with the same respect you would a firearm.
- Always aim in a SAFE DIRECTION. Always keep the muzzle of the airsoft gun point in a SAFE DIRECTION.
- Always keep the airsoft gun "ON SAFE" until you are ready to shoot in a SAFE DIRECTION.
- Always check to see if the airsoft gun is "ON SAFE" and unloaded when getting it from another person or from storage.
- Always keep your finger off the trigger and out of the trigger guard until ready to shoot.
- You and other with you should always wear shooting glasses to protect your eyes.
- If your reading or prescription glasses are not safety glasses, make sure you wear shooting glasses over your regular glasses.
- Use Crosman 6 mm plastic BBs only.
- Do not shoot at hard surfaces or at the surface of water. The plastic BBs may bounce off or ricochet and hit someone or something you had not intended to hit. If the plastic BBs should happen to hit a hard surface, do not reuse those plastic BBs because they could cause possible damage to your airsoft gun.
- Replace the backstop if it becomes worn. Place the backstop in a location that will be safe should the backstop fail.
- Do not attempt to disassemble or tamper with your airsoft gun. Use an Authorized Service Station.
- DO NOT MODIFY OR ALTER YOUR AIRSOFT GUN. Attempts to modify the airsoft gun in way may make your airsoft gun unsafe to use, cause serious injury or death and will void the warranty.
- Using unauthorized repair centers or modifying the function of your airsoft gun in any way may be unsafe and will void your warranty.
- Do not put the airsoft gun away loaded. Make sure ALL of the plastic BBs are unloaded from the airsoft gun.
- Always store this airsoft gun in a secure location.
- We are not responsible for any malfunction, accidents, injuries or repair cost resulting from misuse, or by disassembly and modification of the airsoft gun.



THE REPLACEMENT PARTS WILL BE AVAILABLE AT OURS LOCAL DISTRIBUTOR AND DEALERS

Manufacturer & Brand Owner : Forever Good International Ltd.

Worldwide:


Ares Website: <http://www.aresairsoft.com>
 General Enquiries: ares@aresairsoft.com

North America: ZShot

Exclusive Distributor - <http://www.ZShot.com>


Dealer Inquires: Sales@ZShot.com Technical Support: Support@ZShot.com

M249 PARA EXPOSE PLAN




GEAR BOX INSTALLATION


UNIVERSO SIMPER AIRSOFT



STANDRAD GEAR BOX (INCLUDED GB-249-02)



HIGH POWER GEAR BOX (OPTIONAL GB-249-01)



INERIOR GEAR BOX (OPTIONAL GB-249-03)

HOP-UP ADJUSTMENT


UNIVERSO SIMPER AIRSOFT



- EXCESSIVE HOP UP +
- BEST POSITION
- NOT ENOUGH HOP UP -



SPRING RELEASE



WARNING



- . Do not aim or shoot a person or animal as the target.
- . Avoid pulling the trigger carelessly.
- . Always put the gun in a case or bag when you carrying it.
- . Always set the switch lever to the safety position.
- . Do not look into the gun muzzle.
- . Always wear eye protective gear.
- . Store the airsoft gun at the places out of reach by children.
- . Do not disassemble or modify the airsoft gun.