USER RESTRICTED TO 18 YEARS OF AGE OR OLDER

ARES AR-OOG








THE REPLACEMENT PARTS WILL BE AVAILABLE AT OURS LOCAL DISTRIBUTOR AND DEALERS

INSERT BATTERY



FOLDING STOCK



FIRING MODE / SAFETY



HOP UP ADJUSTMENT

The accuracy of an airsoft gun can be greatly increased by adjusting the hop-up, so you have greater control over where your pellets end up.



THE REPLACEMENT PARTS WILL BE AVAILABLE AT OURS LOCAL DISTRIBUTOR AND DEALERS

BOLT LOCK & RELEASE

- Pull cocking lever to position.
 Push to lock bolt.



- Pull cocking lever to the end.
 Release back to position.



SETTING MAGAZINE



DATA OF ARES AR-006 ELECTRIC GUN

AR-006



FEATURES

- Realistic Gas Block and Piston
- Strong Recoil Effect
- Easily Deactivate with a Single Screw
- Easy Power Upgrade
 Realistic Disassemble Process
- Realistic Folding Stock
- Realistic Flash Hider
- Easy Battery Replacement
 Realistic Barrel Lock
- One-piece Aluminium Outer Barrel
- Functional Bolt Lock / Release
- One-piece High Strength Nylon Fiber Body

BATTERY: 8.4V 1500mAH (2/3A) Nunchuck
MAGAZINE CAPACITY: 45rds (6mm BB)

MODE: Full Auto / Semi / Safe
MATERIAL: Nylon Fiber + Zinc Alloy
MOTOR: High Torque Flat Motor
HOP-UP: Adjustable
LENGTH: 505 / 735mm

WEIGHT: 2600g VELOCITY: 300-340FP



SAFETY

- · DO NOT MODIFY OR ALTER YOUR AIRSOFT GUN. Attempts to modify the airsoft gun in way may make your airsoft oun unsafe to use, cause serious injury or death and will void the warranty.
- Always check to see if the airsoft our is "ON SAFE" and unloaded when getting it from another person or from
- Always keep the airsoft gun "ON SAFE" until you are ready to shoot in a SAFE DIRECTION.
- · Misuse or careless use may cause serious injury.
- · Do not look into the gun muzzle.
- Do not ever point the airsoft our at anything you do not intend to shoot.
- You and other with you should always wear shooting glasses to protect your eyes.
- If your reading or prescription glasses are not safety glasses, make sure you wear shooting glasses over your regular glasses.
- Do not put the airsoft oun away loaded. Make sure ALL of the plastic BBs are unloaded from the airsoft oun. . Do not shoot at hard surfaces or at the surface of water. The plastic BBs may bounce off or ricochet and hit
- someone or something you had not intended to hit. If the plastic BBs should happen to hit a hard surface, do not reuse those plastic BBs because they could cause possible damage to your airsoft oun. Use 6 mm plastic BBs only.
- Always put the airsoft oun in a case or bag when you carrying it.
- Always store this airsoft oun in a secure location and at the places out of reach by children.
- Alway treat the airsoft oun as though it is loaded and with the same respect you would a firearm.
- Using unauthorized repair centers or modifying the function of your airsoft gun in any way. may be unsafe and will void your warranty.
- We are not responsible for any malfunction, accidents, injuries or repair cost resulting from misuse, or by disassembly and modification of the airsoft gun.









Manufacturer & Brand Owner : Forever Good (Hong Kong) Ltd.











Ares Website: http://www.aresairsoft.com General Enquiries: ares@aresairsoft.com

North America: ZShot Exclusive Distributor - http://www.ZShot.com

Dealer Inquires: Sales@ZShot.com Technical Support: Support@ZShot.com

