






• PULL LEVER TO SLIDE BUTT STOCK






INSERT/RELEASE MAGAZINE

• INSERT MAGAZINE INTO MAGAZINE WELL





• PRESS BUTTON TO FOLD THE STOCK



• PRESS LEVER TO ADJUST POSITION

• PULL THE LEVER AND ROTATE TO RELEASE/LOCK BARREL HOP-UP ADJUSTMENT

• PULL CHARGING HANDLE ALL THE WAY BACK TO OPEN

• TURN WHEEL UP FOR MORE HOP-UP • TURN WHEEL DOWN FOR LESS HOP-UP

SAFETY CONSIDERATIONS

BUTT STOCK

SPECIFICATIONS ///

MAGAZINE CAPACITY

VELOCITY / ENERGY

POWER SOURCE

BATTERY:

LENGTH:

WEIGHT

FIRE MODE MATERIAL HOP-UP

SAFETY INSTRUCTIONS ///

PRODUCT FEATURES ///

STOCK RELEASE

SLIM MOTOR

EAD ALL INSTRUCTIONS BEFORE USE! GENERAL PRECAUTIONS

9.6v 1200mAH Mini Nunchuck (2/3A) Stick 358-522mm

2220g Long/125 Short/55 Rounds (6mm BB) SAFE / SEMI / AUTO CNC 6063 Aluminum + Nylon Fiber+ Metal ADJUSTABLE

±430 FPS / <2 JOULES





ivisions of Forever Good (Hong Kong) Ltd.

ARES@ARESAIRSOFT.COM















BARREL RELEASE LEVER

RELEASE BUTTON









