ARES AR-028+61-05




Automatic Electric Airsoft Gun Instruction Manual . Always read through this manual before operation

SAFETY


- DO NOT MODIFY OR ALTER YOUR AIRSOFT GUN. Attempts to modify the airsoft gun in way may make your airsoft gun unsafe to use, cause serious injury or death and will void the warranty.
- Always check to see if the airsoft gun is "ON SAFE" and unloaded when getting it from another person or from storage.
- Always keep the airsoft gun "ON SAFE" until you are ready to shoot in a SAFE DIRECTION.
- Misuse or careless use may cause serious injury.
- Do not look into the gun muzzle.
- Do not ever point the airsoft gun at anything you do not intend to shoot.
- You and other with you should always wear shooting glasses to protect your eyes.
- If your reading or prescription glasses are not safety glasses, make sure you wear shooting glasses over your regular glasses.
- Do not put the airsoft gun away loaded. Make sure ALL of the plastic BBs are unloaded from the airsoft gun.
 Do not about at bord surfaces or at the purface of water. The plastic BBs are unloaded from the airsoft gun.
- Do not shoot at hard surfaces or at the surface of water. The plastic BBs may bounce off or ricochet and hit someone or something you had not intended bit. If the plastic BBs should happen to hit a hard surface, do not reuse those plastic BBs because they could cause possible damage to your airsoft gun.
- Use 6 mm plastic BBs only.
- · Always put the airsoft gun in a case or bag when you carrying it.
- Always put the airsoft gun in a case or bag when you carrying it.
 Always store this airsoft gun in a secure location and at the places out of reach by children.
- Alway treat the airsoft gun as though it is loaded and with the same respect you would a firearm.
 Using unauthorized repair centers or modifying the function of your airsoft gun in any way
- may be unsafe and will void your warranty.
 - We are not responsible for any malfunction, accidents, injuries or repair cost resulting from misuse, or by disassembly and modification of the airsoft gun.



BOLT LOCK & RELEASE



HOP UP ADJUSTMENT





FIRING MODE



FOLDING STOCK




SETTING MAGAZINE



STOCK ADJUSTMENT




BARREAL REPLACEMENT




BATTERY INSTALLATION










FRONT/REAR SIGHT ADJUSTMENT



DATA OF ARES AR-028 + GL05 ELECTRIC GUN



- · Metal Gear Box
- · Easy Power Step Up System · Bolt Locking & Functional Bolt Catch
- · QDE System can change in / out
- Barrel in Seconds Quick Detach Grenade Launcher
- · CNC Upper Receiver
- Steel Trigger
 Both Side Mag. Catch
- MAGAZINE CAPACITY: MODE: MATERIAL: MOTOR:
 - HOP-IIP LENGTH
 - WEIGHT: VELOCITY:

BATTERY:


180rds (6mm BB) Full Auto / Semi Auto / Safe Nylon Fiber + Al.Allov High Torque Flat Motor Adjustable 567 / 760-812mm (In 4 Steps)

9.6V 1500mAH Mini (2/3A) Nunchuck

5100g 350-380FPS









Worldwide:

Ares Website: http://www.aresairsoft.com General Enquiries: ares@aresairsoft.com

North America: ZShot

Exclusive Distributor - http://www.ZShot.com Dealer Inquires: Sales@ZShot.com Technical Support: Support@ZShot.com

© Ares 2011, all rights reserved