
# BES SB-001





# **BATTERY INSTALLATION**

USE THE SPECIFIED BATTERY FOR YOUR GUN. 8.4V 1700MAH




# SETTING MAGAZINE






# FIRING MODE / SAFETY




### HOP UP ADJUSTMENT

THE ACCURACY OF AN AIRSOFT GUN CAN BE GREATLY INCREASED BY ADJUSTING THE HOP-UP, SO YOU HAVE GREATER CONTROL OVER WHERE YOUR PELLETS END UP.



## **BOLT LOCK & RELEASE**

PULL COCKING LEVER TO POSITION.
 PUSH TO LOCK BOLT.



1. PULL COCKING LEVER TO THE END. 2. RELEASE BACK TO POSITION.



# **MARNING**



.Do not aim or shoot a person or animal as the target. .Avoid pulling the trigger carelessly.

Always put the gun in a case or bag when you carrying it.

Always set the switch lever to the safety position.

.Aways set the switch lever to the .Do not look into the gun muzzle.

.Always wear eye protective gear. .Store the airsoft gun at the places out of reach by children.

.Do not disassemble or modify the airsoft gun.

### DATA OF ARES SR-001 ELECTRIC GUN

#### SR-001



### FEATURES

- Metal Gear Box
- Easy Power Step Up System
- . Bolt Locking & Functional Bolt Catch
- · Alumiunum Outer Barrel

BATTERY: 8.4V 1700mAH
MAGAZINE CAPACITY: 20rds (6mm Bi
MODE: Full Auto / Ser
MATERIAL: Nylon Fiber +:
MOTOR: High Torque F

HOP-UP: LENGTH: WEIGHT: VELOCITY: 20rds (6mm BB) Full Auto / Semi / Safe Nylon Fiber + Zinc Alloy High Torque Flat Motor Adjustable 980 / 1030mm (In 6 Steps) 3500a

350-380FPS

### SAFETY

- . DO NOT MODIFY OR ALTER YOUR AIRSOFT GUN. Attempts to modify the airsoft gun in way may make your airsoft our unsafe to use, cause serious injury or death and will void the warranty.
- Always check to see if the airsoft our is "ON SAFE" and unloaded when getting it from another person or from
- Always keep the airsoft gun "ON SAFE" until you are ready to shoot in a SAFE DIRECTION.
- Misuse or careless use may cause serious injury.
- · Do not look into the gun muzzle.
- Do not ever point the airsoft oun at anything you do not intend to shoot.
- You and other with you should always wear shooting glasses to protect your eyes.
- If your reading or prescription glasses are not safety glasses, make sure you wear shooting glasses over your regular glasses. Do not put the airsoft oun away loaded. Make sure ALL of the plastic BBs are unloaded from the airsoft oun.
- Do not shoot at hard surfaces or at the surface of water. The plastic BBs may bounce off or ricochet and hit
- someone or something you had not intended to hit. If the plastic BBs should happen to hit a hard surface, do not reuse those plastic BBs because they could cause possible damage to your airsoft gun. Use 6 mm plastic BBs only.
- Always put the airsoft gun in a case or bag when you carrying it.
- Always store this airsoft our in a secure location and at the places out of reach by children.
- Alway treat the airsoft oun as though it is loaded and with the same respect you would a firearm.
- Using unauthorized repair centers or modifying the function of your airsoft gun in any way. may be unsafe and will void your warranty.
- We are not responsible for any malfunction, accidents, injuries or repair cost resulting from misuse, or by disassembly and modification of the airsoft gun.









Manufacturer & Brand Owner : Forever Good (Hong Kong) Ltd.







Ares Website: http://www.aresairsoft.com General Enquiries: ares@aresairsoft.com

North America: ZShot

Exclusive Distributor - http://www.ZShot.com Dealer Inquires: Sales@ZShot.com Technical Support: Support@ZShot.com

© Ares 2011, all rights reserved