




CARBINE P ANTHER™ A-15 HIGH POWER ELECTRIC SOFT AIR

17920

CAUTION! Do NOT use 6mm paintballs with this softair. Shooting paintballs with this unit will result in jamming and will void any warranty. For a proper operation use Expert Cybergun BBs 0.20 g (#83200) and 0.25 g (#83205). Never aim at a person. Wear protective goggles. Read instruction manual.

DESCRIPTION OF PARTS




NEW
"PISTON RELEASE LEVER"

1) If the feeding cycle stalls, push the release lever upward.

2) Before storing your Softair Gun, always

operate the release lever once in order to preserve the feeding mechanism. This is a preventive maintenance procedure.

8.4V BATTERY



The appropriate battery should be fully charged before using it.

Requires a battery charger NOT included.


HOW TO INSTALL THE BATTERY

In order to remove the hand guard, release it from the barrel by pushing the locking ring backwards in the direction of the stock.

To install the battery, only the lower part of the hand guard needs to be removed.

The battery must be installed in the lower half of the hand guard. The two small plastic walls built in that lower half will guide and maintain the battery in its proper location.

Connect the battery to the loose connector.



HOW TO LOAD BB PELLETS INTO 300 BB MAGAZINE

Load the magazine as shown on the picture. The maximum capacity is 300 rounds.

Magazine replenishment: Rotate the wheel located at the bottom of the magazine as shown by the arrow in this illustration.

Rotate until a "click" is heard. This first step will convey BBs from the storage compartment of the magazine (holds up to 300 rounds) to the feeding mechanism of the magazine for immediate use. Once the available rounds are shot, repeat step one in order to replenish the feeding mechanism again. Repeat at will.



HOW TO INSERT AND RELEASE THE MAGAZINE



Slide the magazine in the receptacle until it is locked (a distinct click will be heard).



Keep the magazine separate from the gun when not using it or for storage purposes.


HOW TO USE SAFETY CONTROLLER



- (AUTO): The gun will fire in full auto mode up to 700 rds per minute.
- (SEMI): The gun will shoot shot by shot in semi auto mode.
- (SAFE): Trigger is locked, power is switched off.
- The safety should be on at all time when not using the gun or when it is stored. The safety should be ON when not actually firing (between 2 firing sequences).

HOW TO CHANGE THE FUSE

- Release the handguard from the body.



- Pull out the fuse.
- Replace the fuse.

ADJUSTABLE SPIN UP® SYSTEM

For easier adjustment use the Spin Up key provided.

Adjust the Spin Up by turning the key clockwise until the desired trajectory is reached.



Insert the key on the Spin Up adjuster as shown.



Reduce the Spin Up by turning the key counter-clockwise if BBs remain stuck in the barrel or have erratic trajectories.


Spin Up® is a technology used in Softair™ guns in order to improve the quality of shooting. It increases the range of Softair™ guns, as the Spin Up® effect rotates the BB at high speed when expelled from the barrel, improving the flying pattern of the BB. The way this technology works is illustrated on the left of this text. A special soft rubber is used in the Spin Up® chamber in order to maximize the Spin Up® effect.

Spin Up® chamber

With Spin Up® effect Without Spin Up® effect

Stained or substandard BB pellets can be a reason of abnormal fire line or malfunction. Use Expert Cybergun BBs 0.20 g (#83200) and 0.25 g (#83205).

SIGHTING DEVICES



• Push the lock (lever) in the direction of the arrow and pull out the stock.

CYBERGUN SA, Air Soft Gun® official licensee for the following brands:
Smith & Wesson, Colt, Uzi, Sig Sauer, Desert Eagle, IMI,
Taurus, Famas, Tanfoglio, Mauser, Thompson, Auto Ordnance,
DPMS Panther Arms, Kalashnikov.

Distributed by: SOFT AIR USA Inc.
e-mail: sales@softairusa.com



www.cybergun.com