

AK47

SOFTAIR® RIFLE



KALASHNIKOV

MIKHAIL T. KALASHNIKOV, INVENTOR OF THE AK-47

WARNING :
 Sale restricted to ADULTS ONLY, 18 years of age or older. Proof of age required at the moment of purchase. SALES PERSONNEL - CHECK PICTURE ID PRIOR TO SALE OF THIS PRODUCT. This softair gun is intended for recreational or training purposes. Protective goggles MUST be worn when operating this SOFTAIR gun. The owner /user should adhere to all federal and state laws governing the ownership and use of softair guns. CONSULT YOUR LOCAL LAW ENFORCEMENT AGENCY PRIOR TO USE. MISUSE OR UNSAFE USE MAY RESULT IN SEVERE INJURIES OR DEATH, THIS IS AN AIR OPERATED SOFTAIR GUN INTENDED FOR USE ONLY BY ADULTS OR MINORS UNDER CLOSE ADULT SUPERVISION. READ THE INSTRUCTION MANUAL CAREFULLY BEFORE USE. ANY ALTERATION AS TO THE COLORATION AND/OR MARKING OF THIS PRODUCT TO MAKE THIS PRODUCT LOOK MORE LIKE A FIREARM IS DANGEROUS, MAY CAUSE CONFUSION, MAY BE MISTAKEN TO BE A REAL FIREARM BY LAW ENFORCEMENT OFFICERS OR OTHERS AND MAY BE A CRIME. IT IS DANGEROUS AND MAY BE A CRIME TO BRANDISH OR DISPLAY THIS PRODUCT IN PUBLIC.



1 To assemble the stock, put it at the back of the gun as shown on the picture.



2 With the screwdriver and screws provided in the box, fix the stock.



3 To release the magazine, push on the lock as shown on the picture and slide the magazine out of the rifle.



4 With the Speed Loader provided in the box, fill the magazine with the appropriate 6 mm rounds (50 max).



5 Then, slide the magazine in the receptacle until it is locked.



6 Slide back the cocking lever shown by a circle on the picture until a click is heard, then release. At this point, one ammo has been engaged in the chamber.



7 To start shooting, aim at a target, put the selector on one of two low positions and pull the trigger (this rifle is a single shot action and requires loading after each shot).



8 Once finished shooting, put the shooting selector back on the "Safe" position. Make sure the rifle is stored empty of any ammunition, magazine removed, and SAFETY ON.



9 Adjustable BAX system. Get the best accuracy whatever your ammo weight & weather conditions. Move the cursor back and forth to fine tune your shot.



10 Rear sight can be adjusted up-down, sliding the lever shown by our circle. For that, push on the lock located on the left of the lever.



www.cybergun.com



www.softair.com

Pictures are for illustration purposes only - Actual product may vary slightly

Mode d'emploi - Notice for use



Don't look inside the barrel.



Never aim at a person



Be careful to avoid rebounding



Keep out of reach of children



Recommended .12g and .20g Cybergun BBs



A question ?
sales@softairusa.com