





A CAUTION

Wear goggles while shooting.

users or older.

airsoft guns.



• This product is suggested for 18 year-old

• Read the whole manual before using the · Buyers and users should comply with the laws and rules defined by the local authority.

· Incorrect use may cause injury or death. Never point at humans and animals with the



# INSTRUCTION MANUAL

# **CM16 300B0T**

### FIRING MODE & SAFETY



Safety On The gun will not fire



Semi Auto Single shot



Automatic firing



Recommended battery type G-11-056 NI-MH 9.6V 1600 mAh

Flash Hider

**Reinforced Grip** 

Hi-cap 450R magazine

Selector Lever

Trigger

Sling Swivel

Magazine Release

- 1. Use high quality battery with the CE approval to avoid any
- Use either 8.4V or 9.6V battery only, battery with voltage too high or too low might damage the product.

Front Sight

**Crane Stock** 

- Remove the battery from the product when it is not in use.

# **CHARGING BATTERY**



- 1. Charge up the battery.
- 2. Charging will be completed after 3 hours.



Pull out the butt plate from the upper part.



Take out the battery stop.



clicks into place.



**KeyMod Rail system** 



Adjustable Rear Sight

Reinstall the battery cover and butt

## **LOADING MAGAZINE**





1. Open the top plate of magazine.

2.Load G&G 5.95mm BB pellets into the magazine until chamber is full. 3.Insert the magazine until it clicks.

4. Turn the winding wheel on the bottom of the magazine to tighten the spring. This will allow the BBs to feed through the top of the magazine.

pellets only. Using low quality BB pellets will damage the product and void warranty.

### **HOP-UP ADJUSTMENT**



# **INSTRUCTION MANUAL** CHIC SOUBOT













### **MAINTENANCE**



Remove the magazine.



Return the hop up dial to normal position and insert the cleaning rod from the lead edge of the inner barrel. remove clogged pellets.



down and reaching to the end, and

### TROUBLE SHOOTING



The screw at bottom of the grip. Please use the screwdriver to



Check the wire set contact with motor.

### FRONT SIGHT ADJUSTMENT



Front Sight - Flip up



Front Sight - Press the butten and Fold down

## RETRACTABLE STOCK



Press the stock release lever to



Adjust the position ( 6 position ).

## REAB SIGHT ADJUSTMENT



Rear Sight - Flip up

## **PARTS LIST**

CM16 300BOT 01 Dummy gas tube

CM16 300BOT 02 Gear box CM16 300BOT 03 Barrel set

CM16 300BOT 04 wire

CM16 300BOT 05 Magazine

CM16 300BOT 06 Upper Receiver Set

CM16 300BOT 07 Lower Receiver Set

CM16 300BOT 08 Rail system set

CM16 300BOT 09 Grip

CM16 300BOT 10 Front Sight

Sales Dept. sales@guay2.com , b2b@guay2.com Technology Support Dept. | support@guay2.com PR Dept. pr@guay2.com

Chang | Tel: +886-4-798-9000 | Fax: +886-4-798-9900 No.999, Zhonghua Rd. Shengang Township, Changhua County 50955, Taiwan (R.O.C.)

Taipei Tel: +886-2-2692-2000 Fax: +886-2-2692-4000 11F-3., No.27, Lane 169, Kangning St. Shijr City, Taipei County 22180, Taiwan (R.O.C.)

- CM16 300BOT 11 Motor CM16 300BOT 12 Charging handle set
- CM16 300BOT 13 Butt stock set
- CM16 300BOT 14 Inner barrel set
- CM16 300BOT 15 Rear Sight
- CM16 300BOT 16 Grip Bottom plate
- CM16 300BOT 17 Flash Hider
- CM16 300BOT 18 Stock Tube CM16 300BOT 19 Sling Swivel Mount
- You may purchase all of the groups' parts from G&G support Dep.
- support@guay2com



