



G&G ARMAMENT
AIRSOFT GUNS & ACCESSORIES

www.GUAY2.com
100% Made in Taiwan

COMPONENTS



GR4 AEG Instruction Manual

Manufactured by G&G Armament Printed in Taiwan



WARNING !!

- Adult supervision required.
- Always wear safety goggles when using this product.
- Misuse or careless handling of this product may cause injury.
- May be hazardous up to 50 meters.
- This product is intended for users 18 years or older.
- Read all instructions before using this product.
- The buyer and the user of this product shall adhere to all local laws regulating the usage and the ownership of airsoft guns.


RECOMMENDED BATTERY TYPE

G-11-038
Ni-MH 9.6V 1500mAh (Two-Piece)




CAUTION

1. Please select quality battery with the CE approval, to avoid any unnecessary damage on the product.
2. Please use either 8.4V or 9.6V battery, if different voltage used, it might damage the product.
3. Remove the battery from the product when it is not in use.
4. Do not wet nor incinerate the battery, nor to deform the terminal.



1. Charge up the battery.
2. Charging will be completed after 3 hours.



Push the upper handguard forward and pull the knob toward flash hider then pull out upward.



Connect battery plug with connector till a click sound is heard.




Insert the battery into lower handguard then reinstall upper handguard.



SAFETY ON
The trigger cannot be pulled



SEMI AUTO
Single shot



FULL AUTO
Automatic firing

FIRING MODE & SAFETY

CAUTION

It is strongly recommended the use of G&G BB pellets only. Using low quality BB pellets will shorten product life span and void product warranty.

SETTING MAGAZINE



Open the cover of magazine.



Load G&G 5.95mm BB pellets into the magazine.



Close the cover plate then turn the gear until the sound changes.



Insert the magazine firmly till a click sound is heard.

HOP-UP ADJUSTMENT

CAUTION

Do not catch your fingers in the dummy bolt. Never hold the gun sideways as the BB pellets will curve right or left.



Turn to **Normal** Turn to **Hop**

Too much Hop-up. (Turn the adjust lever toward **Normal**)

Best Position.

Not enough Hop-up. (Turn the adjust lever toward **Hop**) or Too much Hop-up. (Turn the adjust lever toward **Normal**)



True to the faith of mimicking real life firearms, G&G is proud to present its new Pneumatic Blow Back system to its line of airsoft guns. Conventional airsoft blow back utilizes tow hook springs to mimic real life bolt actions, which often lead to excess wear and tear and poor reliability in the gear box. To alleviate the problem of conventional systems, G&G has independently developed the Pneumatic Blow Back system; a piston driven, gas operated mechanism to better mimic real life bolt actions. This new technology utilizes compressed air to move the bolt, which enables the action without adding extra stress to the gear box. This class leading system represents a significant milestone in the airsoft industry.

- TAIWAN**
Patent No : M300797
- USA**
Patent No : 11/488698
- HONG KONG**
Patent No : 06107627.0
- JAPAN**
Patent No : 實願2006-1459

- EUROPEAN UNION**
Patent No : 460191 814454
- CHINA**
Patent No : 200620122468.9
- DENMARK**
Patent No : BA2007 0069
- U.K.**
Patent No : 614422.4



New Blow Back Pneumatic System



GR4 G26 Instruction Manual

G&G ARMAMENT
AIRSOFT GUNS & ACCESSORIES

www.Guay2.com
Manufactured by G&G Armament
Printed in Taiwan



RETRACTABLE STOCK (GOS-V1)

CAUTION

Keep the selector on Safe mode until you are actually ready to shoot.



Press the stock release lever to unlock.




Adjust the position (6 position).



Extra Storage Space - Press the button then pull out.

SIGHT ADJUSTMENT



WINDAGE KNOB (left / right adjustment)
ELEVATION KNOB (up / down adjustment)



Rear Sight - Flip down or up



Front Sight - Flip down or up


MAINTENANCE



Remove the magazine.



Return the hop up dial to normal position and insert the cleaning rod from the lead edge of the inner barrel.



Be aware to have the rod facing down and reaching to the end, and remove clogged pellets.

TROUBLE SHOOTING



Adjust screw when the gear noise becomes shrilly.

The screw at bottom of the grip. Please use the screwdriver to adjust.



No operation


Check the wire set contact with motor.

OPTIONAL PARTS

G26 Laser & LED build-in Hand Guard Set



LASER BATTERY SETTING




Push the upper handguard forward and pull the knob toward flash hinder then pull out upward.



Pull out the cover and insert the CR123A battery.

LED LIGHT BATTERY SETTING



Unscrew both side and take off the front barrel.



Open the cover and insert the CR123A battery.

PARTS LIST

- | | | | |
|--------------|--------------------------|--------------|----------------------------|
| GR4 G26 - 01 | Flash suppressor | GR4 G26 - 17 | GMAG-V1 magazine |
| GR4 G26 - 02 | Front barrel set | GR4 G26 - 18 | Lower receiver set |
| GR4 G26 - 03 | Lower handguard set | GR4 G26 - 19 | Trigger guard set |
| GR4 G26 - 04 | Upper handguard set | GR4 G26 - 20 | Selector plate |
| GR4 G26 - 05 | Hop-up set | GR4 G26 - 21 | Rear frame lock pin set |
| GR4 G26 - 06 | Slip ring set | GR4 G26 - 22 | Grip set |
| GR4 G26 - 07 | Inner barrel | GR4 G26 - 23 | Motor set |
| GR4 G26 - 08 | Upper receiver set | GR4 G26 - 24 | Grip bottom set |
| GR4 G26 - 09 | Charging handle set | GR4 G26 - 25 | GOS-V1 stock set |
| GR4 G26 - 10 | Port cover set | GR4 G26 - 26 | Gear box set |
| GR4 G26 - 11 | Front frame lock pin set | GR4 G26 - 27 | Barrel base set |
| GR4 G26 - 12 | Bolt catch set | GR4 G26 - 28 | Blow back pneumatic piston |
| GR4 G26 - 13 | Selector lever set | GR4 G26 - 29 | Charging plate |
| GR4 G26 - 14 | Magazine catch set | GR4 G26 - 30 | Charging upper cover |
| GR4 G26 - 15 | Stock washer | GR4 G26 - 31 | Selector plate |
| GR4 G26 - 16 | Enhanced rod set | GR4 G26 - 32 | Rear Sight |

MANUFACTURED BY G&G ARMAMENT

ADDRESS Changhua / No. 999, Zhonghua Rd., Shengang Township, Changhua County 50952, Taiwan
Taipei / 11F-3, NO.27, Lane 169, Kangning St, Shijr City, Taipei County 22180, TAIWAN

E-Mail Sales Department / sales@guay2.com
b2b@guay2.com

Technology support Department / support@guay2.com


WEBSITE www.guay2.com

TEL Changhua / 886-4-798-9000
Taipei / 886-2-2692-2000

FAX Changhua / 886-4-798-9900
Taipei / 886-2-2692-4000

Dealer

Please consult your dealer or G&G for overhaul maintenance and technical guidance.



▶ You may purchase all of the groups' parts from G&G support Dep.
▶ E-Mail: support@guay2.com