

AIR MODEL FIREARMS

1/1 SCALE HIGH PERFORMANCE ASSEMBLED

UNIVERSAL SNIPER
AIRSOFT






注意:使用前請詳閱說明書

Notice: Read instructions completely before use.


安全裝置 Safety

保險位置(關) Safety(off)


保險位置(開) Safety(on)





HA-101 SERIES





HA-102 SERIES




HA-113
HA-116
HA-109 SERIES




HA-112 SERIES



HA-114



HA-118 SERIES



HA-117 SERIES




HA-120
HA-124 SERIES



UNIVERSO SNIPER
UNIVERSO

■ 裝彈方法 □ Feeding BB pellet



- 按下可退下彈匣
- Press this button to reject cartridge.

- BB彈入口
- BB pellet input entrance.



- 裝彈時推桿向下拉
- Push back feeding pin when load BB pellet.

- 入彈匣時推到底如聽“答”一聲即到定位
押下彈匣卡筈，彈匣即會脫離
- While loading the magazine, push it in ward to the bottom till a "tick" sound is heard. press the magazine release catch, the magazine will fall off from the stock.



- 拉到底
- Slide back entirely.



- 放手讓滑套回覆
- Then release slide



- 扣引板機
- Pull the trigger to shoot.



UNIVERSO AIRSOFT

■ 正確使用空氣軟槍，可享受愉快的射擊，但是錯誤的使用方法非常危險，務必遵守下列注意事項

□ Caution!




■ 射擊時最好戴護目鏡
□ Be sure to wear shooting glasses or Goggle when shooting

■ 不用時要把槍置於高處（小孩拿不到的高處）
□ Put the gun beyond the reach of kids



■ 不可用眼睛探視槍口
□ Don't peep at the muzzle

■ 不可朝人射擊
□ Don't aim at people even if it is unloaded



■ 射擊的瞬間，才可以把手指接近扳機擊扣
□ Don't touch the trigger until the moment of shooting

■ 確定射擊的方向均安全後才可以射擊
□ After making sure that there is nobody nearby



■ 避免粗魯的動作，發生危險
□ Avoid a rough operation

■ 不使用時，應將彈匣取出，並取下子彈
□ When the gun is not in use remove the magazine and unload BB pellets

