


NORMAL GRIP TYPE AUTO SUPER SHOTGUN HARDBALL II

THIS GUN CAN EXPEL METALLIC PROJECTILES OR SPOT MARKERS SUCH AS 6 MM PAINTBALLS THROUGH THE FORCE OF AIR PRESSURE.

Item# 27721
27713

CAUTION! never aim at a person.
Wear protective goggles.
Read instruction manual.


1 - GENERAL DESCRIPTION




2 - LOADING OF BB PELLETS

- a) a) Press magazine catcher and slide magazine out.
- b) b) Have lever caught on the lower groove and load pellets (about 30 rounds)
- c) c) By inserting magazine into the gun lever will be out from the groove automatically and loading can be completed.

3 - HOW TO SHOOT



ABOUT SPIN UP®?



Stained or substandard BB can be a reason of abnormal fire line or malfunction. Use Cybergun standard ammunitions.

“Spin Up®” is a technology used in Softair™ guns in order to improve the quality of shooting. It increases the range of Softair™ guns, as the Spin Up® effect rotates the BB at high speed when expelled from the barrel, improving the flying pattern of the BB. The way this technology works is illustrated on the left of this text. A special soft rubber is used in the Spin Up® chamber in order to maximize the Spin Up® effect.

**Cyber
GUN**

www.cybergun.com

CYBERGUN SA, Air Soft Gun® official licensee for the following brands :

Smith & Wesson, Colt, Uzi, Walther, Springfield Armory,
Sig Sauer, Desert Eagle, IMI, Taurus, Famas, Tanfoglio,
Mauser, Thompson, Auto Ordnance.

Distributed by : SOFT AIR USA Inc.
e-mail : sales@softairusa.com


**SOFT
AIR**
USA

WARNING! NEVER SHOOT THIS GUN AS TURNED AROUND!


The extra 6 bullets reserved inside the action pipe of this gun can be shot occasionally when turning the gun around and never attempt to shoot this gun as it turns around.

ATTENTION! NE JAMAIS TIRER AVEC CE FUSIL EN POSITION RETOURNÉE

Les 6 billes supplémentaires stockées dans la goulotte interne de ce modèle sont nécessaires à son fonctionnement. Si l'on retourne le fusil comme le montre le schéma ci-dessous, elles peuvent être tirées occasionnellement. Il est donc conseillé, par mesure de sécurité, de ne jamais retourner le modèle pour tirer.



O



X