

HANDLING CAUTIONS AND  
INSTRUCTION MANUAL

# E-04

AUTOMATIC ELECTRIC GUN



Enhanced  
**HOP  
UP**  
SYSTEM

UNIVERSO SNIPER  
AIRSOFT



## WARNING



Only for 18 years  
old or up

Operation of this air gun for competition use is restricted to users younger than 18 years old.



Injury caution

Since the field of fire can be about 50 to 60 meters, careless shooting may cause eye damage or other injuries.



Careful reading of  
Handling cautions and  
instruction manual


Always read through this HANDLING CAUTIONS AND INSTRUCTION MANUAL carefully before operation. Operate the air gun with full recognition of warnings and cautions.

Always read through this manual before operation.

Users Restricted to 18 Years of age or older



**ATTENTION YOU WILL BE PUNISHED IF YOU SHOOT MISCHIEVOUSLY.**



Those who shoot mischievously or train the gun on people or animals will probably be punished by law.

**ATTENTION THE SAFE LID SHOULD COVER THE MUZZLE.**



Please cover the muzzle with the safe lid, so that the BB bullets won't be shot randomly.

**ATTENTION THE MUZZLE SHOULD BE DIRECTION AT THE SAFE DIRECTION.**



The muzzle should not train on people or animals or any where that would cause danger. Please cover the lid except shooting.

**ATTENTION DON'T LOOK CLOSE TO THE MUZZLE AT ANY TIME.**



Your eyes will be hurt if the BB bullets shoots your eyes by chance, it is very dangerous. So don't look close to the muzzle at any time.

**ATTENTION DON'T SHOOT CASUALLY.**



Shoot casually will cause great danger, so please shoot before you take away the lid, and aim at the object.

**ATTENTION DON'T SHOOT WHERE THERE ARE PEOPLE OR TRANSPORTATION.**



The soft ballistic shooting place should be in the safe arena, those places where there are people or transportation are not allowed to shoot.

**Adjust length at 3 position.**

Necessary goods, which are not included in the complete set

● 9.6V SD TYPE Mini Battery Pack

● Exclusive Charger for Mini Battery

Use the specified battery for the gun, 9.6v, 1100mah hyper command SD type mini battery, avoid use of non-standard or other brand name batteries. Otherwise, the originally designed functions will not be obtained.



**WARNING** Do not use undesignated batteries made by other companies. In such case, it may press the barrel that reduces the speed of shot or lowers hit probability.

Use the specified battery charger which is applicable to the above battery.

Use the correct battery and charger according to respective instruction manuals. We will not be held responsible for any accident or damage caused by wrongful operation or usage of non-specified batteries.

**COMPONENT NAMES**



**Selector and Safety Setting (Always set the safety lever to SAFE until immediately before firing.)**




Set the selector correctly in position; otherwise, malfunction may occur.



<p><b>Selector position</b></p> <p>SEMI</p>	<p><b>SEMI AUTOMATIC (Single Shot)</b></p> <p>The gun will fire one shot each time the trigger is pulled.</p>
<p><b>Selector position</b></p> <p>FULL</p>	<p><b>FULLY AUTOMATIC (Automatic Firing)</b></p> <p>The gun will fire automatically while the trigger remains pulled.</p>


**Retractable Stock**



✕ Adjust to the most comfortable position.



**Dial for adjustment**




Make sure absolutely no waste or dust gets into the adjusting dial


● Pulling the charging handle will expose the hop up adjustment dial in the port cover.

● The best position is where the bullets fly horizontally, and the longest flying distance is obtained.

- Too much hop-up (Return the lever towards NORMAL)
- Best position
- Not enough hop-up (Move the lever towards HOP)







## Removing Clogged Bullets

- ❶ Remove the magazine .
- ❷ Insert the cleaning rod from the lead edge of the barrel.

※ Make sure to clean the barrel chamber whenever bullets are removed.

- ❸ Be careful so that the angled part of the cleaning rod faces down, and remove clogged bullets.



## INSTRUCTIONS FOR LOADING BULLETS!

- Installation  
Make sure to set the magazine upwards and connect it firmly until a click sound is heard.



### 1. to be used as handle



### 2. to be used as stand

