


E-03

AUTOMATIC ELECTRIC GUN SERIES

AVAILABLE FOR OVER 18 YEARS OLD
HANDLING CAUTIONS AND INSTRUCTION MANUAL



UNIVERSO SNIPER
AIRSOFT



 WARNING	
 Only for 18 years old or up	Operation of this air gun for competition use is restricted to users younger than 18 years old.
 Injury caution	Since the field of fire can be about 50 to 60 meters, careless shooting may cause eye damage or other injuries.
 Careful reading of Handling cautions and Instruction manual	Always read through this HANDLING CAUTIONS AND INSTRUCTION MANUAL carefully before operation. Operate the air gun with full recognition of warnings and cautions.

Always read through this manual before operation.

ATTENTION YOU WILL BE PUNISHED IF YOU SHOOT MISCHIEVOUSLY.



Those who shoot mischievously or train the gun on people or animals will probably be punished by law.

ATTENTION THE SAFE LID SHOULD COVER THE MUZZLE.



Please cover the muzzle with the safe lid, so that the BB bullets won't be shot randomly.

ATTENTION THE MUZZLE SHOULD BE DIRECTION AT THE SAFE DIRECTION.



The muzzle should not train on people or animals or any where that would cause danger. Please cover the lid except shooting.

ATTENTION DON'T LOOK CLOSE TO THE MUZZLE AT ANY TIME.



Your eyes will be hurt if the BB bullets shoots your eyes by chance, it is very dangerous. So don't look close to the muzzle at any time.

ATTENTION DON'T SHOOT CASUALLY.



Shoot casually will cause great danger, so please shoot before you take away the lid, and aim at the object.

ATTENTION DON'T SHOOT WHERE THERE ARE PEOPLE OR TRANSPORTATION.



The soft ballistic shooting place should be in the safe arena, those places where there are people or transportation are not allowed to shoot.

Necessary goods, which are not included in the complete set

● 9.6V SD TYPE Mini Battery Pack

● Exclusive Charger for Mini Battery

Use the specified battery for the gun, 9.6v, 1100mah hyper command SD type mini battery, avoid use of non-standard or other brand name batteries. Otherwise, the originally designed functions will not be obtained.


WARNING Do not use undesignated batteries made by other companies. In such case, it may press the barrel that reduces the speed of shot or lowers hit probability.

Use the specified battery charger which is applicable to the above battery


Use the correct battery and charger according to respective instruction manuals. We will not be held responsible for any accident or damage caused by wrongful operation or usage of non-specified batteries.

COMPONENT NAMES

Front Sight (Up Down)



Rear Sight (Far/Near)



Take out to fix the rail




Press to resist to unload the knob

Removing Clogged Bullets

※ Make sure to clean the barrel chamber whenever bullets are removed.

- ❶ Remove the magazine
- ❷ Insert the cleaning rod from the lead edge of the barrel.
- ❸ Be careful so that the angled part of the cleaning rod faces down, and remove clogged bullet.



INSTRUCTIONS FOR LOADING BULLETS!

- **Installation**
Make sure to set the magazine upwards and connect it firmly until a click sound is heard.



Open the magazine

Insert 6mm BB bullets supplied by .

CAUTION The magazine is capable of containing 360 rounds.



Move the gear with hand clockwise until it is fully tight, and the bullets will be sent up automatically.



