

MODEL KC-42 系說明書

MODEL KC-42 INSTRUCTION MANUAL



SNIPER
AIRSOFT

NO.KC-42 系列
NO.KC-42 SERIES

- ★ CO2直壓無BLOW BACK
FIXED SLIDE CO2
- ★ 裝彈數(單排彈15發)
CAPACITY 15 BB(SINGLE COLUMN)
- ★ 一支鋼瓶可擊發數(約200發)
CO2 CONSUMPTION BY 1 CARTRIDGE (AROUND
200 SHOOT)
- ★ 有保險功能
SAFETY FUNCTION
- ★ 6mm BB彈
6mm BBs

KWC® 建瑋玩具工業股份有限公司
KIEN WILL TOY INDUSTRIAL CO., LTD.

地址：台南市自由路2段209巷5號

ADD : NO.5,LANE 209,SECTION 2,ZIH YOU RD.,TAINAN,TAIWAN

TEL : 06-2691815-7

FAX : 06-2698364

e-mail : sales@kwcgun.com

WEBSITE : www.kwcgun.com

K08-00644-DH

射擊/SHOOTING

射擊前的準備 BEFORE SHOOTING



1. 按下卡榫
PRESS THE BUTTON
2. 取出彈匣
RELEASE THE
MAGAZINE


3. 使用六角板手 (5mm 或 3/16") 反時針方向放鬆螺絲至鋼瓶可置入位置。
Please take the enclosed hexagonal wrench in the box and release the bottom screw by counter clockwise until you get enough space to put CO₂ cartridge in the magazine.



4. 從側邊置入 CO₂ 小鋼瓶 (鋼瓶盡量貼合另一側)。

Install the CO₂ cartridge from magazine flank (try your best to make CO₂ cartridge touch the other side of magazine tightly.)

5. 再以順時針方向鎖緊螺絲至 CO₂ 小鋼瓶被刺破入氣。
Screw the bottom screw by clockwise until the magazine is charged by CO₂ cartridge completely.
6. 拉下滑粒。
Pull the magazine follower down.
7. 逐一逐入 B.B 彈 (可填裝 15 發)。
Load the BB pellet by pellet.



射擊 SHOOTING

1. 將裝有 CO₂ 小鋼瓶和 B.B 彈的彈匣置入槍本體內 (有喀噠聲)，準備射擊。
Ready to shoot after reloading the magazine with full of CO₂ cartridge and BB.



2. 瞄準目標物扣引扳機，即可擊發。
Aim the target and pull the trigger.



※注意：在長期不使用的狀態下，請將彈匣內的氣體洩放掉。

※CAUTION: Release all of the gas in the magazine when it is unused in long-term period.

安全裝置 SAFETY

可射擊
SAFETY OFF



保險
SAFETY ON



故障/BREAK DOWN

關於本商品 ABOUT

- § 上蓋無滑動功能。
- § There is no Blowback function.
- § B. B彈擊發完後，亦無滑套止動功能。
- § There is no Hold Open function.
- § B. B彈擊發完後，便是空發扣引。
- § If the BB runs out, this pistol could still shoot by empty magazine. But there should fire nothing from barrel.
- § 擊鐵可獨立旋轉，但無撞擊功能。
- § Un-functional Hammer.

故障的原因與排除 BREAK DOWN FAQ

1. 不良的B. B彈是造成卡彈的原因，請使用品質優良的KWC B. B彈。
Bad quality BB is the main reason to make BB jam. Please use the best quality BB, KWC BB.

2. 當卡彈時，請盡可能先取出彈匣，再以不傷槍管的軟質細棒(不可大於6mm直徑)，從槍口置入清除。
When you meet with BB jam, please release the magazine at first and use the soft stick (no bigger than 6mm) to clean the barrel out.
3. 當扣引扳機時，此時B. B彈即同時在上膛階段，不可扣引一半時又回復，因為如此的動作，將有可能上膛兩發B. B彈。
When you pull the trigger once, the BB will be in breech immediately. The breech will get stock with 2 BB when you pull the trigger uncompletely then pull it again.
4. 使用一段時間後，請再次用中性矽油脂潤滑撞針及扳機軸心。
Please spray the lubricant into firing pin and trigger pin.



請務必嚴格遵守 使用說明指導書 USE BEFORE READING MANUAL SERIOUSLY

THIS PRODUCT ONLY USE FOR 14 YEAR OLD ABOVE. WE WILL NOT BE RESPONSIBLE FOR ANY ACCIDENT OR MALFUNCTION CAUSED BY IMPROPER HANDLING, MODIFICATION, ALTERATION OR DISASSEMBLING OF THE KWC AIR/GAS HOBBY PISTOL. YOU COULD ENJOY THE SHOOTING EXERCISE ACCORDING TO THE CORRECT OPERATION.

1. NEVER BRANDISH OR FIRE THIS GUN AT ANY PEOPLE, ANIMAL PUBLIC OR PRIVATE PROPERTY
2. DO NOT PUT YOUR FINGER ON THE TRIGGER EXCEPT SHOOTING.
3. DO NOT LOAD ANY BBS EXCEPT SHOOTING
4. ALWAYS BE AWARE OF YOUR SURROUNDING BEFORE SHOOTING AND SELECT A SAFE AREA FOR TARGET PRACTICE.
5. KEEP OUT OF REACH OF SMALL CHILDREN.
6. DO NOT FIRE THIS GUN AT A FRAGILE OBJECT AND MAKE SURE NO SUCH OBJECT IS BEHIND YOUR TARGET.
7. DO NOT USE OTHER BB THAN THE KWC'S BB OR RE-USE IT.
8. DO NOT MAKE ANY UNAUTHORIZED MODIFICATION ON THIS GUN OR BB BULLET.
9. DO NOT LOOK DIRECTLY INTO THE GUN.
10. ALWAYS WEAR EYE PROTECTION OR GOGGLE TO PREVENT INJURIES WHEN YOU ARE SHOOTING.

★使用玩具槍時，請務必戴上保護眼鏡或面罩。

★Wear protective eye wear & face mask when using airguns.



★不可攜帶玩具槍在公共場所行走，請務必放在袋子或盒子內。

★always transport an airsoft airgun inside a locked carrying case, make sure it's unloaded, never carrying your airsoft sport gun in open view, as a concealed weapon, or brandish an airsoft airgun in public.



★使用玩具槍時，請務必詳讀說明書內容。

★read and understand the operating and safety manual using your airsoft airguns.



★請不要由槍口向內探視。

★do not directly into the barrel to avoid accidental discharge of bb.



★請不要在公開場合使用玩具槍，也請不要拿玩具槍對準人或動物

★never brandish of fire airsoft airguns in public, or people beyond a certified and regulated airsoft sport arena, brandishing a gun in public is against the law, serious consequences could arise.




★請按認後再發射的彈方向，附近無人取動物存在。

★be aware of you surroundings to avoid accidents.



★不可任意將玩具槍進行改裝或加工。

★do not disassemble or modify your airsoft airguns, doing so will void all warranty service but authorized centers only, removal of the orange safety barrel marking is a federal offense.



EVEN YOU KNOW IT IS ONLY A TOY GUN, BUT PEOPLE MIGHT THINK IT IS. 請不要忘了，雖然自己知道這只是玩具，但不知道的人，會以為這是真槍。

