

# RACCOON®

## »» AIRSOFT COMPACT TRACER


### PRODUCT INFORMATION

- **WEIGHT:** 60 gr.
- **LENGTH:** 65 mm.
- **DIAMETER:** 29 mm.
- **THREAD:** 10 mm. CW
- **MATERIAL:** Aluminium
- **INCLUDES:** 14 mm. CCW Adapter
- **BATTERY:** ± 20K Shots
- **FREQUENCY:** Up to 2100 RPM.

#### • LA CAJA INCLUYE:

1x Raccoon® Compact Tracer  
1x Manual

1x USB Charging wire  
1x 14mm. CCW Adapter



### USE MANUAL

#### • ON / OFF MANUAL MODE:

1. **ON:** Press the switch, the indicator will flash 1 time per second.
2. **OFF:** Press the switch and turn off the LED.

#### • ON / OFF AUTOMATIC MODE:

1. **ON:** It turns on after 3 consecutive shots.
2. **ON:** It turns on after making a movement of 0.5 m.
3. **OFF:** It turns off after 40 min. without activity.

SWITCH / LED



### CHARGE THE TRACER BATTERY

1. Unscrew the front cover of the Tracer and insert the Micro USB cable into the port.
2. When the LED emits a green light, unplug the charging cable and screw the front cover again. The battery is already charged.
3. When the LED emits a red light, it indicates that the battery is depleted and needs to be charged, the tracer will turn off automatically.



MICRO USB



### INSTALATION



1. Screw the Tracer directly into the gun.

2. In rifles use the 14mm CCW adapter.

### IMPORTANT INFORMATION

Internal high voltage circuit, do not handle.

Never look directly into the gun barrel when installing the Tracer, Avoid accidents.

LED indicator: Green - Charged correctly / Red - Low battery.

Clean the inner tube and prevent dirt from entering the Micro USB charging port if it does not work well.



raccoonairsoft.com