



[back to top](#)


PPSH Airsoft Gun Load the Curved Magazine



1




2



3



3





[back to top](#)

PPSH Airsoft Gun Battery Installation



1. Open the end cover.
2. Press the upper-end button to release the end cover.




3. Turn the end cover aside and pull out the connector wire to connect the battery.
4. Turn back the end cover to the original position and lock it by pressing the dummy screw.

[back to top](#)

PPSH Airsoft Gun Ho Up Adjustment

Pull the cocking lever backward and lock it as the safety mode





[back to top](#)

Warning

Sale restricted to ADULTS ONLY, 18 years of age or older.

Proof of age required at the moment of purchase.

Protective goggles and mouth protection **MUST** be worn when operating this airsoft gun.

Never look into the barrel with bare eyes.

Never point the gun to another person within shooting range.

Do not shoot at any target with hard surface within close range. Ricochet pellets may injure yourself.

Do not brandish in public, do not alter the coloration and warning-such an action is dangerous and may be a crime.
DISASSEMBLING (TAKING APART) THIS SOFTAIR PRODUCT VOIDS ALL WARRANTY. PRODUCT MUST BE RETURNED IN ITS ORIGINAL PACKAGING.