

**Operation Stages:**

**Warning:** Always keep the Softair™ pointed in a safe direction!

1. POINT IN A SAFE DIRECTION
2. TAKE THE SAFETY OFF
3. COCK THE GUN POINTING DOWN
4. AIM AT TARGET
5. PULL THE TRIGGER SAFELY

**Important:** Always keep in mind that a Softair™ gun can shoot even if the gas tank seems to need refill or if the magazine is empty (a bb bullet can still be in the barrel!)


Always leave the gun unloaded unless you are shooting with it

**Cocking an air gun:**



Point the gun in a safe direction and make sure not to have the finger on the trigger. Cock the Softair™ gun moving back the slide until you hear the distinctive "Click" of the spring locking. Let the slide move back forward slowly.

**Filling gas into a gas gun:**



Wrong



Correct



Wrong

Only use the genuine gas for Softair™ guns. Always fill the magazine like shown on the picture above: the bottle and the magazine must stay aligned vertically. Always fill with the bottle upside down and press firmly. Immediately stop when gas overflows. It means that either the tank is full or you are not refusing using the correct magazine-bottle alignment.

**Warning:** When the gas tank is inside the magazine always remove the magazine for filling operations. If not, always keep the Softair™ gun pointed in a safe direction when filling the gas tank!

A leak can lead to have the gun shoot with a bullet or something else remaining in the barrel!

**Warning:** Be very careful when using gas and a Softair™ gas gun. Some gases sold are extremely flammable they can cause explosion and injuries! Always keep away from any flame, heat sources, sparks or cigarette! Always keep out of reach of children and use only with adequate ventilation! Follow all the instructions and warning written on the gas bottle. Immediately take care of a gas leak! Leaking gas is very cold and can cause injuries to your skin and your hands. Use protective gloves.

**Loading bb bullets into the magazine:**



For a regular magazine: Using your finger maintain the cursor at the bottom of the magazine. Using the quick loader, maintain the funnel aligned with 3 the hole on the top of the magazine. Fill the magazine. You can also fill the magazine with bullets or one by one if you do not have a quick feeder.

For an updated magazine: adjust the feeding pipe to the top of the magazine. Fill the pipe with bb bullets using a bullets quick loader then push the bb bullets inside with the plastic stick. You can also fill the magazine with bullets or one by one if you do not have a quick feeder.

**Caution:** You should only use genuine bb bullets manufactured by Soft Air USA. Using other brands may be dangerous, jam or damage your Softair™ gun. By the same token, do not load and fire previously used bb bullets. They could be cracked, chipped or out of mechanical tolerances, may be dangerous, jam or damage your Softair™ gun. Only use new bb bullets!

**How to use the gun?**


**Warning:** Never point a Softair™ gun at a person, an animal or anything else you do not want to shoot at. At close range, plastic bullets rebound strongly on plane surfaces.

**Step 1: Put the safety "On"**

Some examples for some Softair™ guns:



Desert Eagle® 50AE  
Safety On Safety Off



Taurus® PT99  
Safety On Safety Off



MICROUZI®  
Safety On Safety Off



Colt® Delta Elite  
Safety On Safety Off

**Caution:** Some guns have a red dot when the safety is "Off".

**Step 2: Cocking the gun**

Softair™ guns need to be cocked before shooting, in order to obtain the power of the spring. Some models cannot be cocked with the safety on, refer to the specific manual of your gun to verify this. Cock only one time before each shot otherwise more than one bb bullet will get into the barrel and jam the gun.

**Caution:** Some Softair™ Guns cannot be cocked if the safety is "ON" switch the safety to "OFF" and cock very carefully!

**Caution:** Electric and gas Softair™ Guns do not need to be cocked before shooting. They are immediately ready to shoot when the safety is OFF. Additional caution is required with these Softair™ guns!

**Caution:** Only cock your Softair™ gun only if you are planning on shooting immediately after. Never let your Softair™ gun cocked when you are not using it! If you have a gas Softair™ gun use it until the gas tank is empty. If you have an electric Softair™ gun disconnect and remove the batteries!




**Step 3: Aim at a target you are sure of**  
Aim at the target as shown on the picture above

Picture Copyright © Soft Air USA Inc. 2009 all rights reserved

Picture Copyright © Soft Air USA Inc. 2009 all rights reserved




Shoot only at a genuine Soft Air USA target, Sticking Gel Target or Net Target, which trap bb bullets efficiently and avoid any rebound! To avoid if missing the target, place a soft surface such as a large cloth or blanket behind the target!

 **Caution:** Never shoot at a hard surface or a wall. BB bullets will rebound at you and can cause injuries!


#### Stage 4: Put the safety "Off"


Put the safety "Off" as described in the specific manual of your Softair™ gun and in the examples in Stage 1. If there is a red dot on your Safety, the red dot should be hidden when the Safety is "Off".


 **Warning:** At this point extreme caution is required. The gun has now the capacity to fire if the trigger is pulled!


#### Stage 5: Fire at the target

You should now be able to shoot aiming at an appropriate target! Never aim at pets or people! When you are ready, pull the trigger until the shot occurs.


 **Warning:** while shooting, maintain your hands on the grip only!

 **Caution:** If you want to shoot again, repeat all steps of the process until the magazine is empty. When you decide to stop shooting, remove the magazine and shoot one last time to make sure that no bb bullets remain in the barrel (some Softair™ guns will not allow this since an automatic safety is activated when removing the magazine from the gun).


 **Warning:** While shooting, if the slide of your Softair™ remains in the backward position, this means the magazine is empty but not the chamber, one bb bullet is still inside! Let the slide go back in its normal position by pushing down the lever on the left side located between the trigger and the slide, or remove the magazine. Do not forget to shoot the last bb bullet remaining in the barrel!

 **Warning:** Gun misfires! Perform these checks: Is the magazine replenished with bb bullets? Has the Softair™ gun been cocked correctly? Is the gas tank full? Is the battery or the dry cells charged? If all the answers are Yes, there could be a problem. For Technical assistance call your dealer or Soft Air USA at 1 866 SOFTAIR (1-866-763 82 47).

**Warranty:** Softair™ guns carry a limited 30 days warranty for all product defects. The warranty starts at the time of purchase. The warranty becomes automatically void in the following cases of damages caused by: improper operation of your Softair™ gun, dropping it, usage in extreme temperatures, attempting to dismantle it, usage of bad quality bb bullets instead of the recommended genuine bb bullets, failure to carry out routine maintenance (see below).

 **Warning:** Store carefully your Softair™ gun. Store it its box and out of the reach of children with the safety On, the magazine removed and unloaded, the gun unloaded and not cocked!

**Maintenance of your Softair™:**

 **Warning:** Carefully clean your Softair™ pointed in a safe direction. The gun should be unloaded and not cocked with the safety On and with the magazine removed.

**Oil and grease:** Use the genuine APS3™ Spray Oil to lubricate regularly your Softair™. For a handgun, insert the spray tube in the muzzle. Briefly spray and remove. This will oil the rubber O-ring of the barrel as well as the slide runners. For a rifle, insert the spray tube in the magazine hole to oil the rubber O-ring of the barrel.

**Batteries for electric Softair™ guns:** For Mini guns using dry cells, only use new alkaline cells and respect the polarity! For electric rifles with a Cad/Ni Batteries, recharge the battery each time before using your Softair™. Use the appropriate charger and often check the temperature of the battery during charging cycle. Immediately disconnect the charger if the battery heats excessively to prevent overload, damage or explosion! Connect the battery, respecting the polarity, only when you are shooting!

**Adjustable Spin Up System:** Some Softair™ guns have an adjustable Spin Up System, the adjustment depends on the weight of the bb bullet and the distance of the target.

Choose a medium adjustment at first and then make gradually adjust.

**Cleaning the Softair™:** your Softair™ has many plastic parts, clean it with a soft cloth and plastic cleaning product!

#### Never attempt modify your Softair™!

In all cases, Soft Air USA Inc., all retailers or distributors and dealers, cannot be held liable for any consequences resulting from the use of any Softair™ product or accessories by the purchaser or any other person!

Colt® is a registered trademark of New Colt Holding Corp, used under license from New Colt Holding Corp. All rights reserved. Taurus® Registered Trademark of Forjas Taurus SA Brazil, Desert Eagle™ Trademark of Magnum Research Inc. USA, UZI® Registered Trademark of Israel Military Industries Israel and FAMAS® Registered Trademark of Giat Industries SA France are used under International Exclusive License by JPSA France. All rights reserved.

Copyright© 2000, Soft Air USA Inc. all rights reserved





The only authorized Softair™ guns importer in the U.S.  
**Taurus** DESERT EAGLE **FAMAS** COLT  
 Products manufactured under exclusive worldwide license by JP S.A.

SoftAir™ Guns Softair™ and APS3™ are Trademarks of Soft Air USA Inc.

**WARNING: MISUSE OR UNSAFE USE MAY CAUSE SEVERE INJURIES OR DEATH. ADULT USE ONLY. READ THESE INSTRUCTIONS CAREFULLY BEFORE USE.**

**WARNING: MISUSE OR UNSAFE USE MAY CAUSE SEVERE INJURIES OR DEATH. ADULT USE ONLY. READ THESE INSTRUCTIONS CAREFULLY BEFORE USE. MAY BE DANGEROUS UP TO 200 FEET (61 METERS)**  
 THIS IS A HIGH POWERED AIR OR GAS OPERATED SOFTAIR™ GUN INTENDED FOR ADULT USE ONLY (18 OR 21 YEARS OLD DEPENDING OF STATE LAW). THE PURCHASER AND THE USER SHOULD READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE USING THE GUN AND SHOULD CONFORM TO ALL STATE LAWS CONCERNING THE USE AND OWNERSHIP OF AIR SOFT GUNS.

Descriptions of Softair™'s guns operations are only examples, refer to the specific instruction manual of your gun included in the box to understand how to operate your Softair™ gun!

Introduction:

**Warning symbol:** This symbol alerts you every time there is a very important issue about safety. Injuries or even death can occur. Read carefully all these messages!

Even if your Softair™ is not a firearm, you should take care of your gun exactly like a real firearm.

Even if there is a safety on the Softair™, which locks the trigger, the first and most important safety is the "Safe Behavior of the Shooter" rule. In order to avoid any accident, the shooter should respect all the following safety rules:

Softair™ guns (also called Air Soft Guns) are not toys!!! You must be an adult (at least 21 years old in some states) to purchase a Softair™!

Softair™ guns are so realistic that they can be mistaken for a real firearm (even with the blaze orange muzzle). Do not carry them in public areas: a police officer or any other person could think they are real firearms.


Softair™ guns shoot 6mm plastic bullets with a speed of around 250fps and at a range of around 200 feet.

A Softair™ gun can be dangerous if not used properly, it can cause wounds or even death! Safety Rules:


- Never point a Softair™ gun at a person, an animal or anything else you do not want to shoot at. At close range, plastic bullets rebound strongly on plane surfaces.
- Never load or point the gun until you are ready to shoot safely at the target you have selected. Cock it always in a safe direction and put the finger on the trigger only when you are aiming at your target!
- Never shoot at a hard surface or water or anything that could cause a bounce back or ricochet!
- Never use a Softair™ gun or stand in an area where Softair™ guns are operated without wearing special protective goggles or facemask in order to protect your eyes!
- Never let a minor or a child play with your Softair™ gun!
- Never try to modify any part of the gun or accessories. Never shoot anything else than the genuine 6mm bb bullets!
- Never reuse bb bullets! Use them once only!
- Read the instructions before using your gun!
- Be always careful and act safely with your Softair™ gun!

In all cases, Soft Air USA Inc., all retailers or distributors and dealers, can not be held liable for any consequences resulting from the use of any Softair™ product or accessories by the purchaser or any other person!


Some examples of our Softair™ guns:




Desert Eagle™ 50AE



Taurus® PT99



Micro Uzi®



Colt® Delta Elite

Pictures Copyright© Soft Air USA Inc. 2000 all rights reserved

Before proceeding:

First, put the safety "ON". All models have a safety. Use it each time you are not shooting! Always keep in mind to be "SAFE". On the pictures in the Stage1 you will find some examples of safety locks.