



VegaForce®Company http://www.gb-tech.com.tw

TEL +886-2-22036630 FAX +886-2-22036610 E-Mail service@vegaforce.com.tw

No.68, Jianguo 2nd Rd., Xinzhuang Dist, New Taipei City 242, Taiwan





WARNING: READ INSTRUCTION MANUAL BEFORE USE



TACTICAL PRECISION SNIPER RIFLE 6mm Bolt Action System Series

Manufactured by VegaForceCompany Made in Taiwan





SPEC

- Over all 810/1060 mm
- Weight 5000 g
- Material Metal / Nylon
- Velocity 120 m/s
- Inner Barrel Lenght 420 mm
- Inner Barrel Diameter 6.02 mm
- Caliber 6mm
- Magazine Capacity 40 rounds

WARNING: READ INSTRUCTION MANUAL BEFORE USE

Component Name

CAUTION:

Congratulations with your new ASW338LM Airsoft gun. Read through this manual before use.


Buttstock pad adjustment button (Vertical) Cocking handle Handguard Rail Flash Hider Safety Lever Stock Release Buttstock pad adjustment button (Horizontal) Magazine Release Button Handguard Handguard Ra **Dummy Bolt Catcher** Adiustable Cheek Piece Buttstock pad Handguard Rail Magazine Trigger Pistol Grip Folding Stock Monopod




NOT A TOY. Adult supervision required. Misuse or careless use may cause serious injury or death. Always wear eye-protection when using this products. Read and follow instruction carefully before use. This product is a high-powered Airsoft gun, recommended for adult use (18 years and up.)

Stock Assembly


Adjust Folding Stock




■ The package includes main body, a stock and a screw.




Use the allen wrench (included in box) to tighten the screw.




Push the button to release the hinge.




■ Make sure the stock is stable.




Push the button to adjust the buttstock pad vertically.




Pull the monopod and fold it downwards.



Adjust the height of the monopod by rotating the handle.




Press the button to adjust the buttstock pad horizontally.




Press the monopod upwards to lock it in place.


Adjust Folding Stock




Push the stock upward to unfold.



Release the screw to adjust the cheek piece.




Push the button to close the stock in place.




■ The cheek piece can be adjusted vertically.

Adjust Grip




Release the screw inside the grip.



Adjust the grip horizontally.


Safety

Firing




Safety position.






Push the magazine release button and pull out the magazine.




■ Insert the magazine until a click is heard.


Firing




■ Move the cocking handle upward.




Off safe position.




■ Load 6mm BBs into the magazine.




Pull back the cocking handle.



Push the cocking handle forward.




Pull the trigger when ready to fire.




By applying a back-spin to the BBs when firing, the trajectory of BBs can be altered in order to obtain better flight and precision of the BBs-referred to as the Hop-up system. There are two types of Hop-up systems; the fixed and the adjustable. The adjustable Hop-up system allows for fine-tuning are trajectory of the bbs.

Move the cocking handle downward to close the bolt.




■ Gradually rotate the allen wrench (included in box) forward and fire a round or two to see the effect.






- The Hop-up function can be unstable the first 200-300 rounds after applying oil. Oil should be applied for ca. every 10,000 rds. fired.
- Turning the Hop-up dial excessively can cause the BBs to clog the Airsoft gun and damage the piston and gears. Reset the adjustment dial to normal and readjust the Hop-up.

ASW-338LM PARTS LIST



Warning



Always use precision 6mm BBs for this Airsoft gun. Never use any used or damage BBs.



Always wear safety goggles when using your Airsoft gun.



Do not look directly into the gun barrel.



 Never aim nor shoot at people nor animals. Always set the selector in "safe" position.
(except when you are ready to shoot a target.)




■ Be sure of what is around the target.



Select a safe place for operation the Airsoft gun. Avoid shooting in public places.



When transporting your Airsoft gun always set the selector lever on "safe", and place the Airsoft gun in a case or bag.



■ Keep the Airsoft gun away from under 18-year-old personnel.



Do not disassemble gun yourself.
Always contact your local retailer.

No modify introduction.



NOT A TOY. Adult supervision required. Misuse or careless use may cause serious injury or death. Always wear eye-protection when using this products. Read and follow instruction carefully before use. This product is a high-powered Airsoft gun, recommended for adult use (18 years and up.)

