

# 





#### FIRING MODE




#### BATTERY INSTALLATION


#### USE THE SPECIFIED BATTERY FOR YOUR GUN 9.6V 1700MAH



#### **BOLT LOCK & RELEASE**



### HOP-UP ADJUSTMENT



#### SETTING THE MAGAZINE







- . Do not aim or shoot a person or animal as the target.
- . Avoid pulling the trigger carelessly.
- . Always put the gun in a case or bag when you carrying it.
- . Always set the switch lever to the safety position.
- . Do not look into the gun muzzle.
- . Always wear eye protective gear.
- . Store the airsoft gun at the places out of reach by children.
- . Do not disassemble or modify the airsoft gun.

## DATA OF M4-FF-L ELECTRIC GUN

BATTERY: 9.6V 3300mAH

**MAGAZINE CAPACITY: 130rds (6mm BB)** 

**MODE: Full Auto / Semi / Safe** 

MATERIAL: Nylon Fiber + Al.Alloy

**MOTOR: High Torque Flat Motor** 

**HOP-UP: Adjustable** 

LENGTH: 940mm

**WEIGHT: 3430g** 

**VELOCITY: 350-380F** 

