







Metal Casting

S24A COLOR: BLACK S24B COLOR: KHAKI


WARNING / / /

- FOR AGE 18 OR AROVE
- PLEASE READ THE INSTRUCTIONS CAREFULLY BEFORE USE.
 MISUSE OR CARELESS USE MAY CAUSE SERIOUS INJURY.
- USER SHOULD OBEY TO THE LAWS REGARDING THE USAGE AND OWNERSHIP OF GAS GUNS.
- FACIAL PROTECTION IS REQUIRED.







3 Operation




Pull the safety lever backward in order to make the safety function valid.




Push the safety lever forward in order to remove the safety function.





4 Trigger System Adjustment



Loose the two screws & take out the outer barrel and trigger system.



Make sure the safety function is works and cocking lever doesn't start before you adjust the trigger lock.

it by pulling downward.



7 ! WARNING















In no event shall Classic Army or any of our partners to light the state of the special, incidental, or consequential damages in consequential dam

PRODUCT ADVISORY

WARNING! Do not change, obscure, alter, remove, or obliterate any coloration or markings on this pure. The coloration and/or markings on this product, including the blaze orange barrel tip are designed to comply with applicable sale and regulations.

WARNING! This product may be mistaken for a firearm by law enforcement officers or others. Any person who changes, afters, removes, or obliterate any coloration or markings that are required by state or federal law or regulation, in any way that makes this product look more like a firearm is guilty of a misdemeanor.

WARNING! The open display, brandishing and/or exposing of this product in any "public place" may be a crime. The term "public place" means any area opened to the public, including but not limited to streets sclerally bridges alleys, plazas, parks, driveways, front yards, parking lots, automobiles, whether moving or not, and buildings opened to the general public including those that serve food or drink, or provide entertainment, and the doorways and entrances to buildings or dwellings.

WARNING! Every person who, except in self-defense, draws or exhibits this product in a fire-ale-ling manner against another in such a way as to cause a reasonable person apprehension or fear of bodily harm is guilty of a misdemeanor purishable by imprisonment in the county jail for a term of not less than 30 days.



Przeczytaj instrukcję przed użyciem ! Read user manual before use !



Podczas zabawy/gry zawsze używaj gogli lub okularów ochronnych.

When shooting at a target or playing a game, you must wear goggles or any other eye protection,



Do zabawy/gry wybieraf tylko bezpieczne miejsca Please select a safe place to play!



Kulki BB mogą pozostać w lufie nawet po wyjęciu magazynka. Nie zaglądaj do lufy! To może być bardzo niebezpieczne!

BBs might remain in the barrek after the magazine has been removed. Do not look into the muzzle! It is extremely dangerous!



Przerabianie i modyfikowanie repliki we własnym zakresie może spowodować jej trwałe uszkodzenie, które nie objęte jest gwarancją. Disassembling or modifying the gun may cause serious damage-to your gun.



Nigdy nie trzymaj palca na spuście chyba, że jesteś gotowy do strzału. Zawsze ustawiaj selektor ognia w pozycji SAFE gdy nie strzelasz z repliki. Never put your finger on the trigger unless you are ready to shoot. Always set the selector switch to the safe position when you are notfiring the gun.



Trzymaj replikę z dala od dzieci? Please keep away from children!



Nie celuj i nie strzelaj do ludzi lub zwierząt. Do not aim or fire at a human or animal.



Podczas transportu zabezpiecz prawidłowo replikę (transportuj ją w pudle lub pokrowcu).
Please put the gun in a case or a carring bag when transporting your airsoft gun.