

ZCOMTAC IV HEADSET



A WARNING

The output of the level-dependent circuit of this hearing protection may exceed the external sound level.

The output of the electrical audio circuit of this hearing protector may exceed the daily limit sound level.

IMPORTANT!

For the best protection, brush aside hair around the ears so the ear cushions fit snugly against the head. Spectacle frames should be as thin as possible and fit close to the head.

Peaksounds



Digital electronic sound reproduction for excellent sound reproduction. Excellet sound quality with perfect location hearing, up to 4 times amplification, it can use as a bug to hearing the whispers of the enemy[indoor], just like a spy.

Noise prevent



Special material of foamin cousions in each earcup provide excellent reproduction of ambient sounds. You can clearly hearing radio communication even in an extreme conditions.

Communication



Noise reduction rating of 18db you can learly communicate with your colleagues even when others are shooting. Excelent compatible with Ztac's PTT series.

Active hearing protector



We all know that a shooter has to protect his ears to prevent life long hearing damage. To solve this issue it's Ztac's duty. Our electronics component will instantaneously suppress harmful impact noises to 82dB inside the earcups.

OPERATION MANUAL







Open the headband. 2.Slide out the cups.

3. Adjust the height of the cups while pressing the headband up or down.

BUTTON HANDLING



- On and off,press the above and below bottons together and hold for at least 3 seconds
- Increase volume press the above button
- 3.Decrease volume press the below button





WWW.NEW-ZTACTICAL.com @ 2012 Z trading Limited Co. All rights reserved

BATTERY INSTALLATION

To replace the batteries, insert a tool under the edge of the battery cover. Loosen each side a bit, then lift off the entire cover.Recommend to remove the batteries when storing the hearing protector for a long time. Check the function of the unit after replacing the batteries.



Pried the battery case open with a "|" shape screwdriver.



2.Follow the "+"and -" logo to install AA battery for both side headset.

REPLACEMENT OPERATION



1.ZCOMTAC IV default state is: The microphone installed on the left, conform to most people and most occasions to use, if you need to change the position of the microphone, please follow the following method



2.First, please put the microphone connecting line plug pull out



3. Then, please send the microphone from guide rod downward pull out



5. Then, please plug in the microphone connecting line, (long needle upward)



4.Second, please send the microphone move to the right, installation on the guide rod



Finally, the microphone is already installed on the right side of the headset, you can start using