ACETECH LIGHTER S

說明書

www.acetk.com

*本說明書所記載之所有內容與功能規格廠商有權更動且不另行通知。
*本說明書所記載之所有內容與功能規格將以實物為準。

●產品說明

1. Lighter S是專門為手槍開發的一款體積小重量輕的發光器,
2. 由於Lighter S的體積小,使用者可以輕鬆的改裝到BB槍護木或魚骨內部或置入市售的滅音管,讓使用者的BB槍或滅音管也具有發光器的功能.
3. 隱蔽式電源指示燈設計,夜戰時電源指示燈的光線不容易被發現.
4. Lighter S內部發光元件為高功率紫外線LED可以使綠色夜光彈激發出非常高的亮度,而對於紅光夜光彈所激發出的亮度效能較差.
5. 內部為高壓電路,請勿自行拆解以免發生觸電.
6. 自動關機說明:
   A. 開機後40分鐘無任何射擊,即自動關機.
   B. 電池低電量時,電源燈將以紅光閃爍數次後自動關機.
7. LED電量顯示:(每秒閃爍一次)
   A. 綠光:高電量
   B. 橘光:中電量
   C. 紅光:低電量,當低電量時,LED將快速閃爍數次後自動關機.
8. 使用Lighter S時,當安裝於BB槍上,眼睛絕對不可直視槍口,以避免誤操作或BB槍故障誤擊而發生意外.
9. 為延長內建鋰電池使用年限,每2個月至少充電一次.

●產品使用與操作說明

1. 第一次使用前必須先進行充電,將前蓋以逆時針方向旋開,將MicroUSB充電線分別插入Lighter S與USB充電器,此時充電指示燈將亮起表示充電中.

Micro USB 插槽 — 充電指示燈

2. 當充電指示燈滅,表示充電完成,移除充電線,將前蓋以順時針方向旋緊.
3. 將Lighter S安裝於槍管前方鎖緊.
4. 按下電源開關,電源指示燈將亮起(每秒閃爍一次).

電源按鈕 — 隱蔽式電源指示燈

5. 閒置40分鐘不使用則自動關機.
6. 不使用時則按下電源開關關機,LED指示燈滅.
7. 當電源指示燈顯示紅色快速閃爍數次後自動關機,就表示電池沒電,需要進行充電.

●規格

※ 支援綠色夜光彈.
※ 支援35PRS連發速.
※ 內建鋰電池,充電時間2.5小時.
※ 充電一次可供應22000發夜光彈射擊.
※ LED電源與電量顯示.
※ FCC, CE, ROHS
※ 尺寸:直徑27mm, 總長度67mm
※ 重量32g(不含轉接頭)
※ 配件:
  ▶ 書明書x1
  ▶ MicroUSB充電線x1
  ▶ M11正牙轉M14逆牙轉接頭x1.

ACETECH LIGHTER S

User Manual

www.acetk.com

*All the specifications and contents in this manual are subject to change without notice.
*All the specifications and contents are only for reference, please make the object as the standard.

●Description

1. The Lighter S, is a smallect and lightest tracer unit designed for the pistol.
2. Because of its small dimension, it enables users easily to install it into their silencers or airsoft gun hand-guards as long as their inner space is larger than the dimension of Lighter S. (Diameter: 27mm or 1.06 inches, length: 67.3mm or 2.65inches)
3. Lighter S could light up green tracer BBs with very high brightness but lighten red tracer BBs with medium brightness.
4. Do not disassemble the Lighter S to prevent high voltage electrical shock.
5. It automatically switches off under the following conditions:
   A. Device has idled for 40 minutes
   B. When the battery power is low, after the power indicator blinks in red color for 3 seconds.
6. Remaining power indicator (flash once per second)
   A. Green light: high power
   B. Orange light: medium power
   C. Red light: low power
7. Do not look straight into the muzzle to check the installation of the device to prevent any accident like mistakenly pulling the trigger or firing the gun.
8. In order to extend the built-in Li-Poly battery life as much as possible, please charge it least once every 2 months.

●Instruction

1. Should charge the Lighter S before using it the first time. Please refer to the following steps:
   A. Unscrew the front cap by turning counterclockwise to open the Lighter S.
   B. Insert one end of the MicroUSB charging cable into the Lighter S and the other end into the charger.

Micro USB Port — Charger Indicator

   C. The charger indicator would light on to indicate that the Lighter S is charging now.

Button Power — Power Indicator

2. When the Lighter S is fully charged, the charging indicator would light off. Pull out the charging cable and then screw the front cap by turning clockwise to close the device.
3. Install the Lighter S in front of the muzzle.
4. Press the power button and then the power indicator will blink (once per second).
5. The Lighter S would turn off automatically after leaving it idle for 40 minutes.
6. When not in use, press the button power to turn off the Lighter S as well as the power indicator.
7. The following situations indicate that the battery is dead and needs charging:
   A. You could not turn on the Lighter S.
   B. You could turn on the Lighter S but the power indicator is in red light, flashes quickly a few times and then it turns off.

●Specifications

※ Supports green tracer BBs.
※ Supports up to 35PRS.
※ Built-in li-Poly battery, Charging time: 2.5 Hours.
※ Accessories:
  ▶ MicroUSB charging cable x 1,
  ▶ Adaptor x 1 (M14 anti-clockwise thread to M11 clockwise thread)
※ Fully charged battery would last over 22000rounds.
※ Led power indicator / battery power indicator
※ FCC, CE, ROHS compliant
※ Dimension: Diameter: 27mm (1.06 inch), length: 67.3mm (2.65 inch)
※ Weight: 32g (without adaptor)