



LOADING MAGAZINE








INSTALL/RELEASE MAGAZINE



ILOADING OPREATION & LOAD INDICATOR

• PRESS FORWARD ON THE MAGAZINE RELEASE



1. LIFT THE COCKING HANDLE UPWARD


2. HOLD THE HANDLE AND PULL ALL THE WAY BACK

3. PUSH FORWARD THE SPRING BOLT TO ITS ORIGINAL

UNTIL IT STOPS (LOAD INDICATOR POP OUT)

4. PULL THE COCKING HANDLE BACK DOWN

PRODUCT FEATURES



ASO3

POWER SOURCE LENGTH WEIGHT **MAGAZINE CAPACITY** FIRE MODE MATERIAL HOP-UP VELOCITY / ENERGY

SPRING POWER 465mm 1500g 38rounds SAFE / FIRE Nylon Fiber + Metal AĎJUSTABLE ±430 FPS / <2 JOULES

GENERAL PRECAUTIONS

This merchandise cannot accept tring components from a real trieam, nor be able to chamber / five real ammunitor.
This merchandise is designed to function solely with 6mm airsoft ammunition.
ONLY use high-quality precision plastic BBs designed for 6mm Airsoft guns.
NEVER reuse a BB that is dirty, has been shot from the gun, or otherwise deformed.
Use of contaminated or imperfect BBs could dranage your growth.

ALWAYS transport Airsoft guns in it's original box or an appropriate gun case.
NEVER carry the gun in plain sight.



AMOEBA

















OR GENERAL ENQUIRY, CONTACT US AT ARES@ARESAIRSOFT.COM WWW.AMOEBA-AIRSOFT.COM WWW.ARESAIRSOFT.COM **F** AIRSOFTAMOEBA


SAFE MODE:

LOAD INDICATOR OFF AIRSOFT RIFLE NOT LOADED

• ONLY PULL THE BOTTON PART OF THE TRIGGER FIRE MODE:

• PULL THE TRIGGER FROM THE UPPER PART


SWITCH FIRE MODE



 PULL THE TRIGGER TO SHOOT


LOAD INDICATOR ON

AIRSOFT RIFLE LOADED



• USE A HEX KEY TO ADJUST HOP-UP • DAIL CLOCKWISE FOR MORE HOP-UP

• DAIL COUNTER-CLOCKWISE FOR LESS HOP-UP (HEX KEYS ARE INCLUDED INSIDE PISTOL GRIP)



AMOEBA "STRIKER" S3 AIRSOFT SNIPER RIFLE

AMOEBA "STRIKER" S3 EXPLODED DIAGRAM

