


• ROLL THE WHELL TO PUSH BB UP


SWITCH FIRE MODE /// SAFE MODE: PUSH SWITCH FORWARD SINGLE MODE: PUSH SWITCH TO RIGHT


FIRE MODE: PULL SWITCH BACKWARD

ARES SMG-005




FULL AUTO MODE: PULL SWITCH TO LEFT





INSERT/RELEASE MAGAZINE




• PULL THE TRIGGER TO SHOOT



HOP-UP ADJUSTMENT • TURN WHEEL UP


FOR MORE HOP-UP

• TURN WHEEL DOWN FOR LESS HOP-UP



ADJUST SLIGHT WITH 4 DIRECTION

PRODUCT FEATURES



POWER SOURCE BATTERY: LENGTH WEIGHT MAGAZINE CAPACITY: FIRE MODE MATERIAL HOP-UP: VELOCITY / ENERGY :

9.6v 1200mAH Mini Nunchuck (2/3A) Stick 3040g 300 rounds SAFE / SEMI / AUTO ZINC ALLOY, ALUMINIUM+ WALNUT WOOD **ADJUSTABLÉ** ±430 FPS / <2 JOULES

SAFETY INSTRUCTIONS ///

- FOR ADULT USE ONLY. NOT TO BE OPERATED BY MINORS UNDER THE AGE OF 18. This merchandise does not cor NEVER MODIFY OR ALTER YOUR AIRSOFT GUN. Attempts to modify the airsoft gun in any way could make your airsoft gun unsafe to use, cause serious injury or death, and will

SAFETY CONSIDERATIONS

GENERAL PRECAUTIONS





CAUTION TO PREVENT BATTERY POWER DRAINAGE, BATTERY MUST BE UNPLUGGED AND STORED SEPARATELY FROM AIRSOFT GUN AFTER USE.

Divisions of Forever Good (Hong Kong) Ltd.



















WWW.ARESAIRSOFT.COM

FOR THE LATEST NEWS AND PRODUCT INFORMATION, VISITUS AT



