

M917

UNIVERSO SNIPER AIRSOFT

www.universosniperairsoft.com





Use 6mm BB pellets
1/1 New Generation Airsoft Electric Gun
The All New FALCON Electronic Gearbox

WARNINGS:

- DANGEROUS: NOT A TOY.** Adult supervision required. Misuse or careless use may cause serious injury.
- FOR AGES 18 YEARS AND ABOVE.** Must be 18 years of age to purchase; minors require parent or legal guardian supervision to operate.
- EYE PROTECTION REQUIRED.** Always wear eye and body protection to prevent injury. Do not fire at hard surfaces to prevent ricochet.
- READ INSTRUCTION BEFORE OPERATING.** Follow safe handling procedures at all times. The purchaser and user should conform to all laws governing the use and ownership of airguns.
- DO NOT BRANDISH OR DISPLAY THIS PRODUCT IN PUBLIC.** It may confuse people and may be a crime. Police and others may think it is a firearm. Do not change the coloration and markings to make it look more like a firearm. That is dangerous and may be a crime.

Age: Above 18
Made In China


6 Mag Release Installation



7 Setting The Battery



8 Butt Stock Adjustment



WARNING

Always read through this manual before operation


- Read through this manual before shooting, paying special attention for safe operation.
- Thoroughly understand the warnings and cautions for safe operation.



Always use precision BB Bullets for this air gun. Never use any used BB bullets.

Do not look directly into the gun barrel to avoid accidental discharge of BB.


Never aim or shoot a person or animal as the target. Always set the selector on safety position except when you are ready to shoot a target.




Never hold the gun sideways as the BB bullets will curve right or left. This is due to the HOP-UP system.




Do not brandish in public, do not alter the coloration and warnings- such an action is dangerous and may be a crime.




Select a safe place for operating the air gun, avoiding places where people and cars pass cross or third persons are around.



Always remove the battery and store the air gun in a case or bag and at a place out of reach by children so that they will not be injured during mischievous play.




Disassembling or modifying the gun may generate danger or adversely affect the performance. So avoid disassembling or modifying the air gun.



There are cases that bullets remain in the gun after the magazine is disconnected, pulling the trigger carelessly is extremely dangerous. After towards a safe direction and fire to confirm that no bullets remain in the gun.


1 Charging the Battery (Battery and charger are included)




CAUTION

● Use the correct battery and charger according to respective instruction manuals. We will not be held responsible for any accident or damage caused by wrongful operation or usage of non-specified battery.

2 Components



3 Selector lever and Safety Setting



Warning


To prevent malfunction of the switch do not change the selector lever from semi to full auto while pulling the trigger.




2. Semi auto (Single Shot)
The gun will fire one shot each time the trigger is pulled.

3. Full Auto (Automatic Firing)
The gun will fire automatically while the trigger remains pulled.

4 Rail Cover Installation



- Align holes on rail covers to screw holes on the handguard.
- Tighten screws accordingly.





- Install rail section for more mounting option.

5 Charging Handle Installation



The removable charging handle can be installed on either side


9 Cheek Rest Adjustment




10 Folding Stock



11 Setting The Magazine



12 Sight Adjustment




Warning

Always use the Double Eagle BB Bullet for this air gun. We shall not be responsible for any damage and accidents arising from use of inferior BBs.

Double Eagle BBs (0.12g) (0.20g)



Inferior BBs

13 Variable Hop Up System





14 Maintenance

- Maintenance when Bullet Speed Becomes low
 - Apply Oil as shown below, using the cleaning rod and oiled cotton cloth. Insert cleaning rod into the barrel.
 - To complete the cleaning, use the cleaning rod (with cotton) as shown below. To remove excess oil.



15 Maintenance

- Removing clogged bullets
 - Remove the magazine and return the hop up adjustment to the Normal position.
 - Insert the cleaning rod from the load edge of the barrel, be careful so that the angled part of the cleaning rod faces down, and remove clogged bullets.



For more information pls visit:
https://www.DEAIRSOFT.COM

