

Instruction Manual



鬆開尾托蓋內藏的螺絲來取開尾蓋
Release the screw from the stock



接上電池後再裝回尾蓋
Connect the battery & replace the stock



接上A點及B點之圓軸位來扣上彈箱架
Install the pins at point A & B to secure the magazine holder.



鎖好B點的彈架鎖制
Lock point B.



可用外盒注入子彈於彈箱口
Can fill up the drum with magazine box.




彈箱備有後備上彈制,方便用家在發射前已填滿送彈槽內的子彈,下方為裝9V電池位置
A button for uploading BB to fill up the bullet trough before start. 9V battery required.



打開鎗頂蓋和彈鍊蓋,放回已裝彈的彈箱
於外盒內,將外盒蓋反轉推上

Open both the lid on top of the gun & magazine box,
put the drum inside then turn the lid over and push it up to close.




扣好上彈槽末端的連接扣
Connect the plug at the end of the
bullet trough.



扣穩彈箱的連接扣後,
先蓋好彈架蓋,然後再蓋上鎗頂蓋
After secure the connection plug,
close the magazine holder lid & then the lid at
the top of the gun.



安全制向後推代表被鎖上板機
Trigger locked when safety switch in the back.



將安全制向前推,輕扣板機2-3次將子彈
自動送上彈槽內備用
Push the safety switch to front to unlock the trigger.
You may pull the trigger 2-3 times to upload BB
into the bullet trough.



完成!!
Finish!!

