



www.GUAY2.com PLASTIC











OPTIONAL PARTS



G-12-006 CD13-TRT30GD



G-03-065 Forward Grip-BK (ABS injection)

PARTS LIST

GR16 Wasp- 01	Wasp front kit	
GR16 Wasp- 02	Rail system set	
GR16 Wasp- 03	Rear sight base set	
GR16 Wasp- 04	Rear sight set	
GR16 Wasp- 05	Hop-up set	
GR16 Wasp- 06	Slip ring set	
GR16 Wasp- 07	Inner barrel	
GR16 Wasp- 08	Upper receiver set	
GR16 Wasp- 09	Charging handle set	
GR16 Wasp- 10	Port cover set	
GR16 Wasp- 11	Front frame lock pin set	
GR16 Wasp- 12	Bolt catch set	

GR16 Wasp- 15 Stock washer

Hi-cap 450R magazine Grip Motor set 16 Wasp- 28 Blow back pneumatic pistor GR16 Wasp- 29 Charging plate GR16 Wasp- 14 Magazine catch set GR16 Wasp- 30 Selector plate

MANUFACTURED BY G&G ARMAMENT

ADDRESS Changhua / No. 999, Zhonghua Rd., Shengang Township, Changhua County 50955, Taiwan (R.O.C.) **Taipei** / 11F-3, NO.27, Lane 169, Kangning St, Shijr City, Taipei County 22180, TAIWAN (R.O.C.)

E-Mail Sales Department / sales@guay2.com b2b@guay2.com

Technology support Department /

WEBSITE www.guay2.com

TEL Changhua / 886-4-798-9000

FAX Changhua / 886-4-798-9900 Taipei / 886-2-2692-4000

Dealer

Instruction Manual



SPECIAL SHOOTING Used for precision firing.

Take off the rear sight to install other

FOLDING FRONT SIGHT



COMMON SHOOTING
Used for full automatic firing.



REAR SIGHT ADJUSTMENT

until you are actually ready to shoot.

MAINTENANCE







TROUBLE SHOOTING





Check the wire set contact with motor.



Check the battery and connector.

