


## 10 各部零件說明 Description

### ■ ICS-251 Sportline



## 1 各部名稱 Component Names



### WARNING 警告 電槍使用之注意事項 Maintenance

- 請勿使用回收及劣質的 BB 彈，以減少槍管損耗與避免卡彈的情形發生。
  - 如發現有卡彈的情形，應立即停止射擊，如卡彈後再勉強射擊，則會增加齒輪損耗。請使用內附通槍條，將卡彈清除後才可繼續使用。若完成通槍基本故障排除後仍無法使用時，請回原採購店家或專業經銷商尋求維修服務。
  - 使用前請先確定您的電池已充滿電，當使用中發覺電池即將用盡或射擊速度降低時，應立即更換電池。
  - 請定期使用通槍條清潔槍管，以保持槍支射擊時的準確性及減少卡彈的情形發生。
  - 請勿經常空槍射擊，以減少 BOx 及齒輪不必要的損耗。
  - 不使用本產品時請移除電池，以免電池電力耗盡損壞。
- 使用前請務必詳閱此說明書限 18 歲以上使用  
Always read through this manual before operation.  
User restricted to 18 years of age or older.

內容如有任何更新，將以官方網站公布為準。  
Latest updates will be announced on our official website.



WWW.ICSBBS.COM

\*每一款槍型基本配備不同依實際出貨為主。圖片僅供參考。  
The components/accessories for each model may have kind of differences depending on the actual goods. Images are only for reference.



## 2 齒輪箱拆解 Dissassemble Gearbox

**1** 拉出槍身插銷，卸下護木  
(為了安全，請同時將電池取下並確定槍機已覆位)  
Disconnect battery and release charging handle

Pull out the handguard pin and then remove the handguard

**2** 按壓槍身固定卡榫，將上槍身往前推出  
Press the disassembling button to pull out the upper receiver assembly

**8** BOX 往上拉即可取出  
Take out the gearbox

將折疊托往後拉開  
Pull the folding stock backward

**7** 將槍身兩側槍身螺絲旋下  
Screw off the screws on both sides

**3** 旋下螺絲，取下握把底蓋  
Screw off the pistol grip butt cap

取下馬達  
Pull off the motor

**4** 旋下握把螺絲並卸下握把  
Release the screws and then take off the pistol grip

**6** 將槍身兩側選擇鈕及軸套卸下  
Disassemble the fire selectors on both sides

## 4 折疊托調整 Folding Stock

**1**

按壓槍托卡榫即可折疊  
Press the stock catch button and then fold the stock

**2**

**3**

## 5 H-UP彈道調整 H-UP Adjustment

拉柄往後拉  
Pull the charging handle to the end

調整  
Adjust H-UP

⊗下墜  
Rotate the dial clockwise to make the pellet go up

⊗上飄  
Rotate the dial counter-clockwise to make the pellet go down

## 3 裝電池方法 Battery Installation

**1**

1. 拉開槍身插銷  
Pull out the handguard pin

2. 將下護木往後推  
Push backward the lower handguard

1. 將上護木往上拉開  
Lift up the upper handguard

2. 將下護木往前推  
Push forward the lower handguard

3. 將下護木往下取出  
Take off the lower handguard

**3**

將電池裝入護木並接上電線  
Install the batteries and connect the connector

**4**

依拆卸步驟反向將護木裝好  
Assemble handguard by reversed way

## 6 覘孔調整方式 Rear Sight Adjustment

## 精密射擊調整 Precision Targeting Adjustment

將覘孔依順時或逆時方向旋轉，可變換遠距或近距射擊。  
Adjusting by rotating the rear sight drum clockwise or counter-clockwise

## 7 彈匣使用方式 Magazine Attachment


彈匣上蓋依箭頭方向推開再倒入BB彈  
Open the cover to load BB's

往前按壓彈匣卡榫即可裝上或卸下彈匣  
Press the magazine catch to load or remove the magazine


## 8 通槍條使用方法 How to use a cleaning rod

將通槍條插入並旋轉及前後拉動以清理內管。  
Insert cleaning rod, turn left and right, move back and forward.


## 9 選擇射擊模式 Shooting Mode Setting



保險  
Safety



單發  
Semi Auto



連發  
Full Auto