



DESERT EAGLE™ .50AE ULTRA GRADE SOFTAIR

VELOCITY: 288 Fps - POWER: 0.46 Joule - ADJUSTABLE SPIN UP



1 To remove the magazine, press the release located on the left side of the grip.




2 Slide magazine out.



3 Fill the loading pipe with the appropriate 6 mm plastic BBs. Works best with Cybergun's BBs 0.20 g (item# 71100). Fit the end of the loading pipe to the top of the magazine. It should adjust tightly. Using the rod provided, gently push all the BBs into the magazine.




4 In order to cock the gun, pull slide backward and release.
CAUTION : never aim at a person. Never fire at a hard surface at close range : BBs may bounced back.



5 To start shooting, aim at a target, put the safety on the "semi" or "auto" position (this model is a single shot action and requires loading after each shot). Pull the trigger.



6 Once finished shooting, put the shooting selector back on the "Safe" position.



ADJUSTABLE SPIN UP SYSTEM

7 In order to adjust the Spin Up Up effect, progressively rotate the wheel located on the top of the slide, under the cover shown on the picture. Caution! An excessive Spin Up adjustment may cause a slow down in the velocity of the BB.

SPIN UP SYSTEM

The Spin Up extends the shooting range of softair. The knob on the upper part of the chamber gives the BB an upward spin to extend its flying range. This Spin Up effect depends also on the structure and material of the chamber, CYBERGUN developed special composite rubber for a much better accuracy.

With Spin Up Effect

Without Spin Up Effect



Distributed by:



www.softairusa.com