




1.將A組裝至BOX後，BOX接收穿過紅圈處再與HOP-UP一起組裝並鎖緊；以I固定選擇片。
Assemble A to BOX, and cross the wire assembly to the red circle, then assemble to Receiver with Hop-up. Use I to fix the Selector.



2.將BOX接收穿過紅圈處。
Cross the wire assembly to the red circle.



3.依序將C、D組裝至接收上再將E組裝至D內。此裝置可防止線組再折疊時被此保護夾傷。
Assemble the C and D accordingly, then put E into D. This device is for protection the wire which might be dipped when folds the buttstock.



4.以F固定E後，組裝線組。E的作用在於防止線組固定時線組被夾傷。
Use F to fix E which is in order to prevent the wire be broken when fix the screen.




5.將線組穿過G以紅箭頭方向組裝，再以H固定。
電池規格請用片式7.4V鋰電池 100mm*20mm*4mm
棒狀11.1V鋰電池 95mm*18mm*18mm
To cross the wire to G by red arrow direction, then fixed by H. The compatible batteries are 7.4 V two-piece 100mm*20mm*4mm and 11.1V stick 95mm*18mm*18mm.



6.固定前先檢查線組是否在固定孔下，先將線組安裝，以I固定，組裝個把後以J固定，蓋上個把底蓋。
Ensure the wire be set under the hole, then fixed by I. Assemble the grip by J and put the bottom of grip.



7.將K組裝至槍身，以L固定K及HOP-UP。
Assemble the K to Receiver and use L to fix K and HOP-UP.



8.以M固定內槍管。
Use M to fix the Inner Barrel.



9.將紅箭頭方向組裝後以N固定。
Assemble the N by red arrow direction and use O to fix.



10.以P固定。
Fixing by P.




11.將Q組裝至紅圈處，再將R以紅箭頭方向組裝至槍身，以S固定護木。
Assemble Q to red block, and assemble R to Receiver by red arrow direction. Use S to fix the Handguard Set.



12.將紅箭頭方向組裝後，將黃色個把紅箭頭方向對準組裝至紅圈處。
Assemble the T by red arrow direction and assemble yellow block to red block by red arrow direction.




13.以U固定槍管，再以V固定U。
Use U to fix the Outer Barrel and Use V to fix the U.




14.組裝槍托管，先將紅圈處往外扳開並裝槍托上方，組裝完成後再將紅圈處恢復。
Before assemble the butt stock, be sure to move the part (as red block) outward to the green position, then recover to red position.



15.槍托組裝。
Assemble the Bolt Carrier.



16.上蓋以紅箭頭方向組裝，注意上蓋紅圈處必須與接收槍身紅圈處。
Assemble the top cover by red arrow direction, be sure that the red block on top cover be fixed on Receiver (red block).



17.將W以紅箭頭方向組裝再以藍箭頭方向固定。
Assemble W by red arrow direction and fix by blue arrow direction.

電池規格請用片式7.4V鋰電池 100mm*20mm*4mm
棒狀11.1V鋰電池 95mm*18mm*18mm
The compatible batteries are 7.4 V two-piece 100mm*20mm*4mm and 11.1V stick 95mm*18mm*18mm.