





1 推開彈匣底板
Slide open the baseplate.



2 卸下螺絲
Release the screw.




3 壓下上蓋卡榫(兩側)
Press the catch (both side)



4 由底部推出彈匣本體
Push the bottom of the Magazine.




5 卸下螺絲
Release the screws.



6 將頂彈頭下壓並使之固定
Plug in the follower and hold it.




7 將舊款上蓋與彈匣分離
Release the old cover.



8 組裝新款上蓋前注意箭頭處(頂彈頭)與(卡榫搖臂)的位置
Before assembling the new cover make sure the "follower" and "follower link" is in the right position.



9 將上蓋與彈匣結合，並鎖上螺絲
Put the new cover on and fasten the screws.




10 與彈匣外殼結合(注意上蓋兩側卡榫)
Put the magazine back to the case. (make sure the both catch is inside the case)



11 鎖上螺絲
Fasten the screw.



12 卡入彈匣底板
Slide the baseplate back to the magazine.



恭喜完成
Well done you did it!



氣動彈匣上蓋 置換說明書

GBBR MAGAZINE COVER AND GAS ROUTE BUCKING
REPLACEMENT MANUAL