




Electric air rifle

AK-47

Operational manual



警告
WARNING



限18歲以上使用
For age 18 and older



使用前請詳細閱讀說明書
Read manual before use

MADE IN TAIWAN

PRODUCT ADVISORY

WARNING! Do not change, obscure, alter, remove, or obliterate any coloration or markings on this gun. The coloration and/or markings on this product, including the blaze orange barrel tip are designed to comply with applicable state and federal law and regulations.

WARNING! This product may be mistaken for a firearm by law enforcement officers or others. Any person who changes, alters, removes, or obliterate any coloration or markings that are required by state or federal law or regulation, in any way that makes this product look more like a firearm is guilty of a misdemeanor.

WARNING! The open display, brandishing and/or exposing of this product in any "public place" may cause confusion and may be a crime.

The term "public place" means any area opened to the public, including but not limited to, streets, sidewalks, bridges, alleys, plazas, parks, driveways, front yards, parking lots, automobiles, whether moving or not, and buildings opened to the general public including those that serve food or drink, or provide entertainment, and the doorways and entrances to buildings or dwellings.

WARNING! Every person who, except in self-defense, draws or exhibits this product in a threatening manner against another in such a way as to cause a reasonable person apprehension or fear of bodily harm is guilty of a misdemeanor punishable by imprisonment in the county jail for a term of not less than 30 days.


使用前請詳細閱讀說明書 Read user's manual before use !




無論是在一般射擊或是遊戲的時候
請全程佩帶護目鏡
When shooting at a target or playing a game,
you must wear goggles or any other eye protection.




射擊外請關上保險並請勿將手指伸入護弓內碰觸
扳機, 避免誤擊
Never put your finger on the trigger unless you are ready
to shoot. Always set the selector switch to the safe
position when you are not firing the gun.




請在空曠的場地射擊或是遊戲, 以免造成危險
Please select a safe place to play !



請遠離孩童可以觸及的地方
Please keep away from children!




彈匣卸下後槍管膛內可能還有子彈 無論有沒有子彈
絕對不要向槍口窺視
BBs might remain in the barrel after the magazine
has been removed. Do not look into the muzzle!
It is extremely dangerous!



請勿對人或是動物射擊或將槍口朝向標靶以外的
目標
Do not aim or fire at a human or animal.




請勿嘗試分解, 改造, 改裝槍枝
Disassembling or modifying the gun
may cause serious damage to your gun.




槍枝在不使用時或是攜帶途中, 請放至於槍盒
或是槍袋中
Please put the gun in a case or a carrying bag
when transporting your airsoft gun.

槍枝結構 COMPONENT NAMES



	SRC AK-47 DATA		AK-47 DATA	
型號 MODEL	AK-47	AK-47C	AK-47	AK-47C
全長 LENGTH	870mm	642/880 mm	870mm	642/880mm
重量 WEIGHT	3270g	2800g	3900g	3850g
初速 VALOCITY	90m/s		710m/s	


電池安裝說明 HOW TO INSERT BATTERY




將電池蓋往下壓即可開啟
Pressing the butt plate down




將電池放入並接上接頭
Insert battery and connect the connector



將電線整理整齊
Bend cords to fit the stock




如步驟一將蓋子蓋回
Put the butt plate back




壓下機匣蓋固定鈕 向上掀起機匣蓋即可取下
Press the catch button and lift the receiver top




接電池置入並接上接頭
Insert battery and connect the connector




將電線接頭固定於定位
Put the connectors as picture shows



將機匣蓋前端插入前槍身並下壓機匣蓋直至固定鈕彈出
Put the edge of receiver top under the rear sight and press in the rear until the catch button ejects out




彈匣操作 HOW TO LOAD THE MAGAZINE



將彈倉蓋向上掀開並倒入BB彈
Open the cover of magazine and Insert BBs in to the magazine




依箭頭方向將發條上緊
Turn the gear at the bottom until heard click sound



使用SRC快速撥彈器更輕鬆有效率
Use SRC Mr. ROLL UP could charge the magazine fast and easily

安裝彈匣 HOW TO USE THE MAGAZINE




安裝彈匣時請先將前端卡入槍身，將彈匣往後卡入彈匣卡榫
Insert the magazine as picture shows until heard the Click sound




卸下彈匣時先按下彈匣卡榫 即可卸下彈匣
Press the magazine release button to remove the magazine

射擊選擇鈕操作 SELECTOR LEVER & SAFE



保險 SAFE




全自動 FULL AUTO




半自動 SEMI AUTO

摺疊槍托操作 HOW TO OPERATE FOLDING STOCK




CAUTION
 槍托摺疊伸展時請務必按下卡榫
 ALWAYS PRESS THE BUTTON
 WHEN OPERATE FOLDING STOCK

照門調整 REAR SIGHT ADJUSTING



HOP UP 調整 HOP UP ADJUSTING



- 太強 TOO STRONG
- 佳 BEST
- 太弱 TOO WEAK



操作 Q&A TROUBLE SHOOTING

SYMPTOM 槍枝狀況	CAUSE 故障原因	ACTION 排除方式
不作動 No Operation At all	保險未開 Selector lever set to SAFE	將保險撥至連發或單發 Set the selector lever to AUTO or SEMI
	電池沒電 Battery is not charged	電池充電 Charge the battery
	電池接頭未接 Battery connector is disconnected	接合接頭 Connect the connector
	馬達標準壽命已到(五萬發) Expired motor life (50,000)	更換馬達 Replace the motor
	保險絲燒毀 FUSE is blown out	更換保險絲 Replace the FUSE
馬達有動作 卻不能發射 Motor is revolving but gun doesn't work	齒輪故障 Faulty gear	請至專門店維修 Purchase the replacement gear from the dealer
	子彈卡在槍膛 Bullets are clogged in the chamber	使用通槍條通出子彈 Using the cleaning rod to remove the bullet
	子彈卡在彈匣 Bullets are clogged in the magazine	請輕拍彈匣 並確定使用SRC精密彈 Shake the magazine and confirm use SRC precision BBs
單發不正確 Malfunction of SEMI auto	齒輪正時未對準 Deviation in gear timing	切至連發射擊二~三秒再切至單發 Set to SEMI after firing 2~3 sec in Full AUTO
	控制桿磨損 Faulty gear lever	請至專門店維修 Purchase the replacement parts from the dealer
連發不正確 Malfunction of FULL auto	齒輪正時未對準 Deviation in gear timing	切至保險再切至連發 Set to SAFE first then set to Full auto again
	控制桿磨損 Faulty gear lever	請至專門店維修 Purchase the replacement parts from the dealer
連發速度變慢 Firing circle slow	電池即將沒電 Insufficient battery power	請充電並確認使用SRC專用電池 Charge the battery and make sure use SRC batteries
子彈飛行距離近 Shooting distance short	HOP UP沒作動 HOP UP system doesn't working	調整 HOP UP Adjust HOP UP
	BB彈不良 Faulty BB bullets	請確定使用SRC精密彈 Please use SRC precision BBs
	O環磨損 Faulty O-ring	請至專門店維修 Purchase the replacement parts from the dealer
槍枝異音或其他 Loud or other	槍枝操作不正確 Operation doesn't correctly	請至專門店 Purchase the replacement parts from the dealer

AK SERIES LINE UP

- | | |
|----------------------|--------------------------------------|
| GE-0601-TM | AK47 |
| GE-0601-TM-SE | AK47 WOOD VERSION |
| GE-0602-TM | AK47C |
| GE-0602-TM-SE | AK47C WOOD VERSION |
| GE-0602-TM-LE | AK47C 24K GOLD /WOOD LIMITED EDITION |
| GE-0603-TM | AK-47 β SPETSNAZ |
| GE-0604-TM | AK-47 KRINKOV |
| GE-0605-TM | AK-47 RPK |
| GE-0605-TM-SE | AK-47 RPK WOOD VERSION |
| GE-0606-TM | AK-47 U TYPE |
| GE-0607-TM | AKM-S |
| GE-0608-TM | GALIL |



星虹

STAR RAINBOW TOYS.CO.,LTD

Sole Agent: SPRING TIME (TAIWAN) INC.

<http://www.stti.com.tw>