



Electric air rifle Operational manual

SR4 STYLE

使用說明書



 **警告**
WARNING



限18歲以上使用
For age 18 and older



使用前請詳細閱讀說明書
Read manual before use

注意事項

警告 本玩具為無法改造成為有殺傷力之玩具槍,請勿嘗試改造以免損壞內部精密機構

警告 此玩具槍有可能讓警方或民眾誤以為真槍,導致危險或恐慌,請勿除去或修改槍上之標記.

警告 請勿在任何的公共場所把玩,展示,射擊.或任何導致一般民眾恐慌之行為上述行為有可能違反社會秩序維護法

警告 請勿對標靶以外之人體,動物,射擊.以免造成受傷或損害物品遭受刑責處分

PRODUCT ADVISORY

WARNING! Do not change, obscure, alter, remove, or obliterate any coloration or markings on this gun. The coloration and/or markings on this product, including the blaze orange barrel tip are designed to comply with applicable state and federal law and regulations.

WARNING! This product may be mistaken for a firearm by law enforcement officers or others. Any person who changes, alters, removes, or obliterate any coloration or markings that are required by state or federal law or regulation, in any way that makes this product look more like a firearm is guilty of a misdemeanor.

WARNING! The open display, brandishing and/or exposing of this product in any "public place" may cause confusion and may be a crime. The term "public place" means any area opened to the public, including but not limited to, streets, sidewalks, bridges, alleys, plazas, parks, driveways, front yards, parking lots, automobiles, whether moving or not, and buildings opened to the general public including those that serve food or drink, or provide entertainment, and the doorways and entrances to buildings or dwellings.

WARNING! Every person who, except in self-defense, draws or exhibits this product in a threatening manner against another in such a way as to cause a reasonable person apprehension or fear of bodily harm is guilty of a misdemeanor punishable by imprisonment in the county jail for a term of not less than 30 days.

使用前請詳細閱讀說明書
Read user's manual before use !



無論是在一般射擊或是遊戲的時候
請全程佩帶護目鏡
When shooting at a target or playing a game,
you must wear goggles or any other eye protection.



射擊外請關上保險並請勿將手指伸入護弓內碰觸
扳機, 避免誤擊
Never put your finger on the trigger unless you are ready
to shoot. Always set the selector switch to the safe
position when you are not firing the gun.



請在空曠的場地射擊或是遊戲, 以免造成危險
Please select a safe place to play !



請遠離孩童可以觸及的地方
Please keep away from children!



彈匣卸下後槍管腔內可能還有子彈 無論有沒有子彈
絕對不要向槍口窺視
BBs might remain in the barrel after the magazine
has been removed. Do not look into the muzzle!
It is extremely dangerous!



請勿對人或是動物射擊或將槍口朝向標靶以外的
目標
Do not aim or fire at a human or animal.



請勿嘗試分解, 改造, 改裝槍枝
Disassembling or modifying the gun
may cause serious damage to your gun.



槍枝在不使用時或是攜帶途中, 請放至於槍盒
或是槍袋中
Please put the gun in a case or a carrying bag
when transporting your airsoft gun.

槍枝主要名稱 **Componet Name**



SR4 STYLE ELECTRIC RIFLE	
全長 Over all	760mm/840mm
重量 Weight	2980g
裝彈數 Magazine capacity	300
彈藥 Bullet	6mm
初速 Inetial bullet speed	95m/s 0.2g BB
連射速度 Full auto shotting speed	700-850 / min

M4A1	
全長 Over all	760mm/840mm
重量 Weight	3480g
裝彈數 Magazine capacity	30
彈藥 Bullet	5.56mm
初速 Inetial bullet speed	875m/s
連射速度 Full auto shotting speed	700-1000 / min

1 選擇鈕 保險使用說明 Selector switch and safety setting

保險 safety setting



板機無法扣壓
The trigger can not be pulled

單發 SEMI Automatic
(single shot)



連發 FULL Automatic



2 安裝電池 Battery compartment



1 壓下護木固定環,並取下下護木
Pull the delta ring back and remove the lower handguard



2 將電池放入下護木,並接上接頭
Insert the battery inside the battery guide in the handguard and connect connectors



3 如步驟一裝回護木
Put the handguard back as step one




操作選擇鈕時請勿觸碰板機以免造成危險
Never operate the selector switch while pulling the trigger ! It may cause dangerous !



當位於保險位置時 請勿扣壓板機以免造成故障
Pulling the trigger with the selector switch being set to safe may cause damage !

3 戰鬥托 電池安裝說明

Insert battery into tactical retractable stock



- ① 步驟1.拉下釋放連桿
Pull the release lever
步驟2.將整個戰鬥槍托取下
Take the retractable stock out



- ② 將電池放入戰鬥托本體中
Put battery into the stock




- ③ 蓋回電池蓋並旋緊固定
Put the cover on and fasten



- ④ 將電池放入套筒中並接上接頭
Put the battery in to the tube , and connect the connector



- ⑤ 將電池完全塞入套筒
Make sure put the battery into the tube



- ⑥ 依步驟1 裝回槍托
Put the stock back as step 1

4 固定托 電池安裝說明

Insert battery into fixed stock



- ① 步驟1. 壓下釋放鈕
Press the release button
步驟2. 打開底板
Open the bottom cover



- ② 放入電池並接受接頭
Put the battery into the stock,
and connect the connector



- ③ 將電線塞入槍托蓋回底板
Put the wire into the stock and
close it



注意

請使用SRC精密研磨彈

PLEASE USE SRC PERFCT BB




6mm

○ SRC BB



with
edges

× 表面不平整



offset
halves

× 表面有段差



used,
soiled

× 表面不清潔

5 可變上旋系統 Variable Hop Up system



調整時請勿放開拉柄
Don't let go the charging handle when adjusting the Hop Up



請勿將槍側向射擊
彈道可能無法預測
Never hold the gun sideways as the BB will curve right or left



因槍管精密度極高請
勿使用回收彈或不平
整的子彈，否則導致
卡彈會造成內部損壞
Because a precision
tight bore barrel is
installed. Using dirty
or recycled BBs will
cause a jam and
damage the gearbox.
Do not Recycle BBs!



請小心手指被槍機片
夾住
Be careful not to
catch your fingers
in the dummy bolt


調整Hop Up 系統
Adjustment hop up system

● 最佳水平位置及最遠距離圖示

The best position is when the bullets fly horizontally
and the longest flying distance is obtained



6 彈匣操作方式 How to use magazine



- 握著彈夾 並且依照箭頭方向旋轉彈夾下方的齒輪，當聲音由噠噠轉變成喀喀時便代表發條上緊
Hold the magazine and turn the gear at the bottom Stop turning when the magazine starts to click.



檢查BB彈是否順利的上至出彈口
Make sure the BBs move up to the exit and insert the magazine into the rifle.

- 故障排除
Emergency Recovery



偶爾在連發射擊時有可能BB彈在射擊中途停止
請取下彈匣，定如下圖輕拍或搖動彈匣
There are occasional cases that feed of bullets stop midway during full auto operation
Remove the magazine, shake or hit the magazine.

- 打開彈夾頂部彈倉蓋並且倒入BB彈，彈夾內部可容納300發
Open the magazine hatch at the top of the magazine and insert BBs. The magazine can hold about 300 rounds.

7 歸零校正 Setting the sight

- 前準星(上下調整)
Front sight (Setting the hitting point up or down)

左轉彈著點往下
Turning counterclockwise
lowers the front sight.




右轉彈著點往上
Turning clockwise raises the
front sight.

注意 CAUTION 調整過度會造成準星掉落
The front sight will come off if turned too much

- 照門
Rear sight

照門座往上彈著點往上
Turning the dial up will raise
the rear sight.

照門座往下彈著點往下
Turning the dial down
will lower the rear sight.



- 一般視孔
Battle sight for common shooting



右轉彈著點往右
Turning it clockwise
will move the rear
sight towards the right.



左轉彈著點往左
Turning it counterclockwise
will move the rear
sight towards the left.



精密射擊視孔
Battle sight for
precision shooting

8 六段式伸縮槍托操作 How to use the 6 position retractable stock



② 拉
Pull

① 壓下釋放連桿
Push the release lever

- 六段固定位置
Adjust length of 6 position



最短位置 全長 760 mm
Shortest position 760mm

776 mm

792 mm

808 mm

824 mm

最長位置 全長 840mm
Longest position 840mm

請務必使用SRC製BB彈。因使用不符合規格之BB彈可能導致本體故障。

**Always use SRC BB bullets for this rifle !
We will not be held responsible for any damage and accidents from using BB bullets by other manufacturers**

SRC 0.2g BB



SRC 0.23g BB



SRC 0.25g BB



SRC 0.28g BB



請務必使用SRC製充電電池。因使用不符合規格之電池可能導致故障，或動作不良。

**Always use SRC batteries for this rifle !
We will not be held responsible for any damage and accidents from using batteries by other manufacturers**

8.4v 1000 mAh 9.6v 1000 mAh



8.4v 1600 mAh 9.6v 1000 mAh



8.4v 3000 mAh 9.6v 3000 mAh



操作 Q&A TROUBLE SHOOTING

槍枝狀況 SYMPTOM	故障原因 CAUSE	排除方式 ACTION
不作動 No Operation At all	保險未開 Selector lever set to SAFE	將保險撥至連發或單發 Set the selector lever to AUTO or SEMI
	電池沒電 Battery is not charged	電池充電 Charge the battery
	電池接頭未接 Battery connector is disconnected	接合接頭 Connect the connector
	馬達標準壽命已到(五萬發) Expired motor life (50,000)	更換馬達 Replace the motor
	保險絲燒毀 FUSE is blown out	更換保險絲 Replace the FUSE
馬達有動作 卻不能發射 Motor is revolving but gun doesn't work	齒輪故障 Faulty gear	請至專門店維修 Purchase the replacement gear from the dealer
	子彈卡在槍膛 Bullets are clogged in the chamber	使用通槍條通出子彈 Using the cleaning rod to remove the bullet
	子彈卡在彈匣 Bullets are clogged in the magazine	請輕拍彈匣 並確定使用SRC精密彈 Shake the magazine and confirm use SRC precision BBs
單發不正確 Malfunction of SEMI auto	齒輪正時未對準 Deviation in gear timing	切至連發射擊二~三秒再切至單發 Set to SEMI after firing 2~3 sec in Full AUTO
	控制桿磨損 Faulty gear lever	請至專門店維修 Purchase the replacement parts from the dealer
連發不正確 Malfunction of FULL auto	齒輪正時未對準 Deviation in gear timing	切至保險再切至連發 Set to SAFE first then set to Full auto again
	控制桿磨損 Faulty gear lever	請至專門店維修 Purchase the replacement parts from the dealer
連發速度變慢 Firing circle slow	電池即將沒電 Insufficient battery power	請充電並確認使用SRC專用電池 Charge the battery and make sure use SRC batteries
子彈飛行距離近 Shooting distance short	HOP UP沒作動 HOP UP system doesn't working	調整 HOP UP Adjust HOP UP
	BB彈不良 Faulty BB bullets	請確定使用SRC精密彈 Please use SRC precision BBs
	O環磨損 Faulty O-ring	請至專門店維修 Purchase the replacement parts from the dealer
槍枝異音或其他 Loud or other	槍枝操作不正確 Operation doesn't correctly	請至專門店 Purchase the replacement parts from the dealer

M4 SERIES LINE UP

GE-0501	SR4 CARBINE
GE-0502	SR4 TACTICAL CARBINE
GE-0503	SR4-16
GE-0504	SR4 R.I.S
GE-0505	SR4 416
GE-0506	T-91
GE-0507	M933
GE-0508	SR4A3
GE-0509	SR4SD
GE-0510	SR4COB

PDF creado por: Sniper,
Matadores Airsoft Club, www.matadoresairsoft.com



星虹

STAR RAINBOW TOYS.CO.,LTD

<http://www.starrainbow.com.tw>