

UTG47LE TACTICAL WARHAWK

UTG47SE WARHAWK CQB COMMANDER

SEMI/FULL AUTO AIRSOFT RIFLE


OWNER'S MANUAL



DOUBLE HI-CAP MAGAZINES

UTG TACTICAL SLING

SPEED LOADER



OPTIONAL - UTG 4X32 COMBAT TACTICAL SCOPE WITH RINGS



- ▶ Excellent quality and battle field proven
- ▶ Mil-dot range estimating
- ▶ Finger adjustable precision windage/elevation
- ▶ AccuShot 1" tactical rings
- ▶ Great accuracy performance

OPTIONAL - UTG TRI-RAIL BARREL MOUNT AND POWER FOREGRIP



- ▶ Tri-rail barrel mount for most versatile applications
- ▶ Power foregrip to enhance control and handling
- ▶ Slotted for pressure switch
- ▶ Tail cap compartment for battery storage

- ▶ Rugged and robust construction, hefty weight
- ▶ New generation full metal gear box with precision motor
- ▶ 1200mah battery with great fighting power and lasting shooting performance
- ▶ Precision metal barrel
- ▶ Metal bolt carrier, metal trigger, metal receiver cover
- ▶ Excellent quality metal selector/safety switch
- ▶ Metal front/rear sight with full functionality
- ▶ Durable metal sling housing
- ▶ Adjustable Hop-up systems
- ▶ Great power and excellent accuracy
- ▶ Two high capacity magazines with impressive wind-up design
- ▶ Tactical tri-rail mounting system
- ▶ Deluxe Speedloader
- ▶ UTG deluxe multi-functional 3-point tactical sling
- ▶ Outstanding optional UTG 4X tactical scope package

WARNING: NOT A TOY. FOR AGES 18 YEARS AND UP. MISUSE OR UNSAFE USE MAY CAUSE SEVERE INJURIES. EYE PROTECTION REQUIRED. THE PURCHASER AND THE USER SHOULD READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE USING THE GUN AND SHOULD OBEY ALL LAWS CONCERNING THE USE AND OWNERSHIP OF AIRSOFT GUN. DO NOT BRANDISH OR DISPLAY THIS PRODUCT IN PUBLIC - IT MAY CONFUSE PEOPLE AND MAY BE A CRIME. POLICE AND OTHERS MAY THINK IT IS A FIREARM, DO NOT CHANGE THE COLORATION AND MARKINGS TO MAKE IT LOOK MORE LIKE A FIREARM. THIS IS DANGEROUS AND MAY BE A CRIME.

- Always treat the airsoft gun with the same respect and safety precaution as you would with a firearm.
- Airsoft gun must be kept out of the reach of minors.
- Always wear protective goggles for airsoft sport.
- Use .24 caliber (6mm) plastic BBs only. Strongly recommend using NeonFire Premium Precision Ground 6mm BB Pellets. Low quality BB pellets may clog and damage the rifle. Do not re-use BBs.
- DO NOT MODIFY OR ALTER YOUR AIRSOFT GUN. Attempts to modify the airsoft gun in any way inconsistent with this manual may make it unsafe to use and cause serious injuries.
- Do not store away the airsoft gun loaded. Make sure all BB's are unloaded from the airsoft gun. Always store it in a secure location.



WARNING - CAUTION



Never look into the barrel with bare eyes.



Never point the gun to another person within shooting range.



Do not shoot at any target with hard surface within close range. Ricochet pellets may injure yourself.



Do not brandish in public, do not alter the coloration and warnings - such an action is dangerous and may be a crime.



Never put your finger on the trigger except when you are shooting. Leaving your finger on the trigger is dangerous and may cause unintended shooting.



Pulling the trigger with the safety lever being set to SAFE may damage the gun.



Do not disassemble the gun beyond what is required for operation. Otherwise, the gun may be damaged.



When the gun is clogged, stop operating immediately. Otherwise, the mechanism may get damaged. Make sure to remove clogged pellets before resuming operation.

1 Component Chart

- ① Stock - Battery Compartment
- ② Tactical Tri-Rail Mounting System
- ③ Safety/Fire Selector
- ④ Trigger
- ⑤ Magazine Release Lever
- ⑥ Tactical Rings (Optional)
- ⑦ Tactical Scope (Optional)
- ⑧ Hi-Cap Wind-up Magazine
- ⑨ Spare Hi-Cap Wind-up Magazine
- ⑩ Elevation Adjustable Real Sight
- ⑪ Hop-up Adjustment Switch
- ⑫ Tactical Tri-Rail Barrel Mount (Optional)
- ⑬ Tactical Foregrip (Optional)
- ⑭ Front Sight
- ⑮ 1200mah Battery
- ⑯ Battery Charger
- ⑰ Gun Sling



Warning! DO NOT charge battery over 4 hours. Over-charging is dangerous and will damage the battery.



Warning! Before you follow the assembly instruction, make sure to remove the magazine and set the Fire/Safety Selector to the "SAFE"



2 Load Pellets

- Slide open the Magazine Cap.
- Insert 6mm pellets into the Magazine. It can hold up to 340 pellets(Fig 2.1).
- Close the Magazine Cap.
- Rotate the Wind Up Wheel to draw BBs up into the Ready Tube. Stop when the wheel gets tight.
- Insert the loaded magazine into the gun(Fig 2.2).
- **To remove magazine**, hold the Magazine Release Lever while tilting the Magazine forward to disengage the Magazine.



Fig 2.1



To Install Magazine:

- 1 Insert and align the installation slot at the front of the mag into the gun.
- 2 Tilt the magazine backward to lock into position.

Fig 2.2



Warning! Always use NeonFire Premium Precision Ground 6mm BB Pellets for accuracy and safety. Never re-use pellets.

3 Install/Replace Battery

- Locate the Battery Compartment in Stock.
- Push the Butt Pad downward to open the Battery Compartment(Fig 3.1).
- Disconnect the Battery wire from socket.
- Install or replace the battery.
- Re-connect the Wire Socket. Tuck the battery and wire inside the Stock(Fig 3.2).
- Install the Butt Pad by sliding it upward till it is locked into position(Fig 3.3).




Fig 3.1



Fig 3.2



Fig 3.3

4 Firing (Ensure complete safety of environment before firing.)



- Activating the trigger carelessly is extremely dangerous. Never set the Safety/Fire Selector off the "SAFE" position or put your finger on the trigger unless the protective plug is removed and you are ready to shoot at a target.

1. Semi Auto Shooting and Full Auto Shooting

- Set Fire/Safety Lever to "Semi Auto" position or to "Full Auto" position.
- Hold the gun firmly and rest the stock at a comfortable position.
- Aim the rifle at your target and pull the trigger to fire.



2. Adjust Variable Hop-Up System for Best Shooting

- Locate the Hop-Up Switch under the fake cocking handle at the right side of the rifle.
- Slide the Hop-Up Adjustment Switch to a desired position.
- Shoot a few pellets, exam the trajectory and make further adjustment if necessary.



3. Wind Up More Pellets for Continuous Shooting

While the magazine is designed to hold large capacity BBs, it requires BBs to be fed by batches into Ready Tube. When a batch of BBs is used up, rotate the Wind Up Wheel to draw Bbs into the Ready Tube for more shots.



Note: The hi-cap magazine gives the user continuous shooting fun. Its "Wind-up" design requires feeding more BB's into the Ready Tube before all BB's are used up. It is NORMAL to need to wind up while there are still some BBs left in the Ready Tube. When the gun is set at full auto, it is NORMAL to need to keep winding for enough feed tension for the full-auto mode to work continuously.

5 Maintenance

- Keep the rifle in clean condition.
- Regularly clean the barrel with soft cleaning rod.
- Never used dirty, damaged or distorted pellets.

PDF creado por: Sniper,
Matadores Airsoft Club, www.matadoresairsoft.com

