


COLT FAL CARBINE EXPOSE PLAN



BATTERY INSTALLATION

USE THE SPECIFIED BATTERY FOR YOUR GUN 9.6V 3300MAH




HOP-UP ADJUSTMENT



FETY MODE





- Do not aim or shoot a person or animal as the target.
- Avoid pulling the trigger carelessly.

 Always put the gun in a case or bag when you carrying it.

 Always set the switch lever to the safety position.

 Do not look into the gun muzzle.

- Always wear eye protective gear.
 Store the airsoft gun at the places out of reach by children.
 Do not disassemble or modify the airsoft gun.