

G&G ARMAMENT Complete AEG Series <http://www.gay2.com>



G&G ARMAMENT
Complete AEG Series

GR25

S · N · I · P · E · R

**Instruction
Manual**

GR25

S · N · I · P · E · R

CONTENTS




• WARNING	P2.P3. P4. P5
• COMPONENTS	P6.P7
• BATTERY SETTING	P8
• BATTERY TYPE	P9
• MAGAZINE LOADING	P10.P11
• MAGAZINE INSERT	P12
• FIRING MODE	P13
• HOP-UP AND MOTOR	P14.P15
• FLIP-UP FRONT SIGHT	P16
• FIELD STRIPPING	P17.P18
• TRIGGER GUARD	P19
• MOCK SOUND SUPPRESSOR	P20.P21
• OPTION PARTS AND ACCESSORIES	P22.P23
• SPEC. OF GR25 SNIPER	P24
• CAUTION	P27

WARNING HANDLING CAUTIONS & INSTRUCTION MANUAL
Always read through this manual before operation.




G&G ARMAMENT
Complete AEG Series

警告
WARNING




You may be liable for damaging public or personal property or for injuring a person or an animal even if you only meant to shoot as a "practical joke". Always observe good manners and enjoy fun sport shooting.

警告
WARNING



Never direct the muzzle towards a person, and animal or any other dangerous direction.

警告
WARNING




Select a safe place for operating the air gun, avoiding places where people and cars pass cross or third persons are around.

P.02


P.03

警告
WARNING




Make sure to attach the barrel and safety cap to the muzzle, except when you are shooting. Do this to prevent accidental, sudden discharge and also for dust protection purposes. NEVER pull the trigger while the barrel and the safety cap is attached.

警告
WARNING



Safety procedure:
1 - Attach the safety cap to the muzzle.
2 - Set the selector lever to the safety position.
3 - Remove the magazine.
4 - Remove the battery.

警告
WARNING




Looking into the muzzle is extremely dangerous regardless of BB's having been installed or not. If you get hit in the eye by a BB bullet, you may in worst case, loose your eye sight.

GR25 SNIPER
6mm Electric Semi Auto System

WARNING HANDLING CAUTIONS & INSTRUCTION MANUAL
Always read through this manual before operation.



警告
WARNING




Activating the trigger carelessly is extremely dangerous. Never put your finger onto the trigger unless the safety cap is removed and you are ready to shoot a target.

警告
WARNING



When shooting the air guns for target practice or in a game situation, you and all participants must wear goggles or other eye protective gear. Also, pay attention to ricochets. It is important to pay attention to third parties other than the participants.

警告
WARNING




There may be cases where some BBs remain in the gun after the magazine has been disconnected. After removal of the magazine, direct the muzzle towards a safe direction and pull the trigger to confirm that no BBs remain in the gun, then attach the safety cap.

P.04


P.05

警告
WARNING




When you carry the air gun, attach the safety cap, set the selector lever to the safety position and always put it in a case or bag.

警告
WARNING



Always attach the safety cap to the muzzle, remove the battery and store the air gun in a case or bag and at a place out of reach by children.

警告
WARNING





Disassembling or modifying the gun may adversely affect the performance and make it dangerous.

Components



G&G ARMAMENT
Complete AEG Series



GR25 SNIPER
6mm Electric Semi Auto System

Components


P.06
P.07

▪ Battery setting and battery type




G&G ARMAMENT
Complete AEG Series

1



Open the buttplate cover.

2



Pull out the connector and insert battery into the buttstock.

3



Connecting the connectors then insert into upper receiver and close battery cover.

Recommended battery type:



8.4V 1800mAh Ni-Cd rechargeable battery



GR25 SNIPER
6mm Electric Semi Auto System

▪ Battery setting and battery type

P.08

P.09

▪ Magazine loading



G&G ARMAMENT
Complete AEG Series

1




Connect the BB charger muzzle to the top of the magazine.

2



Feed the BBs into the charger.

3



Push the BBs into the magazine with the charging rod.

50 Rounds magazine(standard)

1



Open the cover on the top of the magazine.

2



Feed the BBs till it's full.

3



Close the cover and turn the gear at the bottom all the way till the clicking sound changes.

430 Rounds Hi-cap magazine(option)

GR25 SNIPER
6mm Electric Semi Auto System

▪ Magazine loading

▪ Magazine insert and release



G&G ARMAMENT
Complete AEG Series

1



To insert the magazine:

Insert a loaded magazine upward and make sure it's properly seated.

2



To release the magazine:

Hold the magazine then press the magazine catch and pull the magazine out.

P.12

P.13

1



Semi auto:

One shot each time when trigger is pulled.

2



Safety on:

Trigger can not be pulled and will not fire.

GR25 SNIPER
6mm Electric Semi Auto System

▪ Firing mode and safety

▪ HOP-UP adjusting



G&G ARMAMENT
Complete AEG Series

1



Pull the charging handel all the way back to open the bolt.

2



Lock the bolt with bolt catch.

3



Push the charging handel back.

4



Turn the adjust dial to variate the hop-up effect.

5



Press the upper part of bolt catch to release the bolt.



When the gear noise become shrilly, turn the adjustment screw on the bottom of the grip.

GR25 SNIPER
6mm Electric Semi Auto System

▪ Motor gear engagement adjusting

P.14

P.15

▪ Detachable flip-up front sight



G&G ARMAMENT
Complete AEG Series



Flip manually

1



To release the front sight:
Unscrew and take the fixing screw off and remove.

2



1



Pull the receiver pivot pin out.

2



Move the upper receiver forward till separate with lower receiver.

GR25 SNIPER
6mm Electric Semi Auto System

▪ Field stripping

P-16


P-17

▪ Field stripping



G&G ARMAMENT
Complete AEG Series

3




Remove the charging handle and bolt

4



Pull the hop-up unit and inner barrel out.

5



Remove the bolt spring and spring guide on the lower receiver.

1



Depressing the trigger guard plunger with a proper tool and open the trigger guard.

2



GR25 SNIPER
6mm Electric Semi Auto System

▪ Trigger guard

P-18
P-19

▪ Attach the mock sound suppressor




G&G ARMAMENT
Complete AEG Series

To install the sound suppressor




1



Insert outer barrel into the sound suppressor

2



Press the fixing rods to lock the sound suppressor.

To remove the sound suppressor:




1



Pull the fixing rods up.

2



Turn and pull the sound suppressor to release.

GR25 SNIPER
6mm Electric Semi Auto System

▪ Remove the mock sound suppressor

▪ Option parts and accessories



G&G ARMAMENT
Complete AEG Series



G-12-001
CARBINE VISIBLE LASER



G-12-002
GREEN LASER POINTER



P-22

P-23



G-01-018
GR25
MOCK SOUND SUPPRESSOR



G-01-044
LEATHER RIFLE SLING (BLACK)
G-01-044
LEATHER RIFLE SLING (BROWN)



G-03-037
RAILED SCOP HIGH RING



G-07-066
FLIP-UP LENS COVER



G-08-044
430 ROUNDS HI-CAP
MAGAZINE



G-05-018
Q.D. SLING SWIVEL MOUNT



G-05-012
Q.D. SLING SWIVEL



G-05-017
STOCK EXTENSION SLING
MOUNT FOR FIXED STOCK

GR25 SNIPER
6mm Electric Semi Auto System

▪ Option parts and accessories

■ SPEC. For GR25 sniper



G&G ARMAMENT
Complete AEG Series

- Built material: **AL6061/Magnesium/Plastic**
- Magazine capacity: **50 rounds(standard), 450 rounds(option)**
- Overall length: **1,000mm(without soundsuppressor)**
- Inner barrel length: **520mm**
 - Weight: **3000g**
- Muzzle velocity: **330 fps. with 0.2g BB**

■ CAUTION

Always attach the safety cap and disconnect the magazine to avoid sudden operation upon connecting the battery.

Be careful so as not to catch your fingers in the movable parts.

Always set the lever to "safe" before firing.

Do not disassemble beyond what is necessary, or the gun may be damaged.

Always use "G&G ARMAMENT" BBs for this gun. We shall not be held responsible for any damage or accidents arising from the use of bullets supplied by other manufacturers.

Since a tight barrel is used, use of dirty BBs or those with burrs causes jamming and possible fatal damage to the gear box.

Turning hop-up dial excessively causes clogging of BB.
Keeping pulling the trigger with BB clogged damages the piston and gears.

Never hold the gun sideways as BB will curve right or left.

We shall not be held responsible for any damage or accidents arising from the wrong operation or modification of the gun.

Disassembly is designed for appropriate maintenance, not for modification.

GR25 SNIPER
6mm Electric Semi Auto System

■ CAUTION

P-24
P-25



Guay Guay Trading CO., LTD.
www.guay2.com

Please consult your dealer or G&G for overhaul maintenance and technical guidance.

DEALER