



SD5 | SD6

ADDITIONAL INSTRUCTION MANUAL

This product not including Dot sight



Components




Parts list



► You may buy all of the groups' parts from G&G ARMAMENT support Dep.
► E-Mail : support@guay2.com

MP5SD5-01
HANDGUARD SET
MP5SD5-02
LOWER RECEIVER SET
MP5SD5-03
UPPER RECEIVER SET
MP5SD5-04
INNER BARREL
MP5SD5-05
HOP-UP RUBBER SET
MP5SD5-06
HOP-UP SET
MP5SD5-07
REAR SIGHT SET
MP5SD5-08
OUTER BARREL SET
MP5SD5-09
COCKING LEVER OUTER TUBE SET
MP5SD5-10
COCKING LEVER SET
MP5SD5-11
FRONT SIGHT SET
MP5SD5-12
BACK HOUSING SET
MP5SD5-13
FLASH SUPPRESSOR SET
MP5SD5-14
ELECTRIC WIRE SET
MP5SD5-15
BARREL HOUSING SET
MP5SD5-16
STOCK SET
MP5SD5-17
MAGAZINE RELEASE LEVER
MP5SD5-18
INNER HANDGUARD SET
MP5SD5-19
SELECTOR LEVER
MP5SD5-20
HI-CAP MAGAZINE
MP5SD5-21
MOTOR SET
MP5SD5-22
GEAR BOX SET
MP5SD5-23
SELECTOR PLATE
MP5SD5-24
GRIP BOTTOM SET





Selector lever

Retractable stock

Front sight

Lower profile mount

Rear sight

Rear sling swivel

Sound suppressor

Cocking lever

Handguard

Release lever

Grip

200 rounds Magazine

Magazine release lever

Trigger guard




Parts list



▶ You may buy all of the groups' parts from G&G ARMAMENT support Dep.
▶ E-Mail : support@guay2.com

MPSSD6-01
HANDGUARD SET
MPSSD6-02
LOWER RECEIVER SET
MPSSD6-03
UPPER RECEIVER SET
MPSSD6-04
INNER BARREL
MPSSD6-05
HOP-UP RUBBER SET
MPSSD6-06
HOP-UP SET
MPSSD6-07
REAR SIGHT SET
MPSSD6-08
OUTER BARREL SET
MPSSD6-09
COCKING LEVER OUTER TUBE SET
MPSSD6-10
COCKING LEVER SET
MPSSD6-11
FRONT SIGHT SET
MPSSD6-12
BACK HOUSING SET
MPSSD6-13
FLASH SUPPRESSOR SET
MPSSD6-14
ELECTRIC WIRE SET
MPSSD6-15
BARREL HOUSING SET
MPSSD6-16
RETRACTABLE STOCK SET
MPSSD6-17
MAGAZINE RELEASE LEVER
MPSSD6-18
INNER HANDGUARD SET
MPSSD6-19
SELECTOR LEVER
MPSSD6-20
HI-CAP MAGAZINE
MPSSD6-21
MOTOR SET
MPSSD6-22
GEAR BOX SET
MPSSD6-23
SELECTOR PLATE
MPSSD6-24
GRIP BOTTOM SET



Battery setting



Retractable stock




Pull the handguard locking pin out.




Remove the handguard.



Set the battery under the outer barrel.




Press the stock release lever to retract stock.



Connect the connector.



Assemble the handguard.



Insert the handguard locking pin.



Finished