

S *CO2 Personal* PORT 321

UNIVERSO SNIPER
AIRSOFT



PATENT AUTO-MOVING GRIP



Quick and easy CO₂
cartridge replacement
design



Quick and easy BB's
loading system

OPERATION MANUAL

WARNING: Not a toy. Adult supervision required. Misuse or careless use may cause serious injury or death read and follow it carefully. All instructions before using. This is a high power air gun recommended for use by those 18 years of age or older.

WARNING: Be sure gun is always pointed in safe direction never point the gun at anyone. Always assume and treat the gun as if it were loaded and ready to fire.

WARNING: By safety consideration, be sure pushing the safety lock to "ON" right after each shot, take out the magazine and remove the unfired BB shots. Do not store the gun and BB shots at a place that the ambient temperature is above 40°C.

WARNING: Empty magazine shooting perhaps shorten gun life.

Learning the Parts of Your New Soft Air Pistol

Learning the Parts of Your New Soft Air Pistol
Learning the names of the parts of your new soft air pistol will help you to understand your owners manual. Use this manual to increase your enjoyment of this soft air pistol (Fig.1)

Operating the Safety

WARNING: Keep the pistol in the "ON SAFE" position until you are actually ready to shoot.

On Save: Press down the safety then push it forward to position "S" (Fig. 2)

Off Save: Press down the safety then push it rearward to position "F" (Fig.2)

Installing CO2 Cartridge

WARNING: Keep hands and face away from escaping CO₂ gas. It can cause frostbite if allowed to come in contact with skin.



⚠ WARNING: CO₂ cartridges may explode at temperatures above 120°F (48.9°C). Do not mutilate or incinerate them. Do not expose them to heat or store CO₂ cartridges at temperatures above 120°F (48.9°C).

⚠ WARNING: Use only CO₂ cartridge which are the 12 gram type.

1. Always point the pistol's muzzle at a safe direction and make sure the safety is at "On Safe" position. (Fig. 2)


2. Press the grip catch to move the grip out automatically and pull it to the bottom of right side. (Fig. 3)

3. Pull down the piercing level, turn it in counterclockwise direction till the space is sufficient to install a CO₂ cartridge. (Fig. 4)

4. Install the CO₂ cartridge into the chamber. (Fig. 5)

5. Turn the piercing level in clockwise direction to pierce the CO₂ cartridge. (Fig. 6)

6. Push back the grip to original position. (Fig. 7)



Loading the BB

1. Make sure the pistol is "On Safe" and always point the gun in a safe direction. (Fig. 2)

2. Press the grip catch to move the grip out automatically. (Fig. 8)

3. Turn the pistol to right side and pull down the BB follower to bottom and fix it into left groove. (Fig. 9)



4. Load the BB into the port. (Fig. 10)
5. Capacity: the 6mm version could be loaded with 12 pcs plastic BB. And the 4.5mm version could be loaded with 17 pcs steel BB.
6. Push back the grip to original position and ready for auto-loading.



Aim and Fire

1. Aim to a safe target. Since the CO2 gun will eject outstanding gas force, player should pay extreme attention on target selection and be aware that improper target would make BB or steel shots rebounded from the target. (Fig. 11)
2. When you are certain that the target, back-stop and surrounding area is safe, position the safety "F" (Fig. 2) pulling the trigger now will fire the gun.
3. Make sure the gun is pointed at a safe target. Once the last BB has been shot from the gun, it is still possible for the trigger to be pulled, but only CO2 will be discharged.
4. After shooting is complete, turn off the safety lock. (Fig. 2)



WARNING

1. If a BB does not fire after completing the operation steps, do not assume that the gun is unloaded. Keep the gun pointed in a safe direction.
2. After a shooting is complete, the gun should be unloaded before storing it. To unload the gun always put "ON" safe "S" position, remove the CO2 cartridge, and remove the BB's From the magazine.
3. High temperatures can produce pressure in the CO2 cartridge and gun that is considerably higher than normal operating pressure. Such increased pressure may prevent the pistol from firing and may result in permanent damage to the gun. The maximum operating or storage temperatures can easily be reached if the gun is left directly in the sun on a bright, sunny day. Therefore the shooter should not expose the pistol to high temperature conditions or direct sunlight for any extended period of time.
4. Rapid firing of the gun will cause temperature reduction in the pistol and CO2 gas. This will result in lower BB velocities and may even lower gas pressure enough so that the pistol will not fire. This condition can be avoided by allowing more time between shots. This permits the gas to increase in temperature and pressure, and produce normal velocities.
5. Care should be exercised to ensure that the gun is not shot with a CO2 cartridge that is low in pressure because a BB may not be expelled from the barrel.

6. A CO₂ cartridge contains gas under pressure, whether or not it has been inserted into a gun. If exposed to high temperatures (such as inside of a closed car in direct sunlight), it could explode. Be sure to store all cartridge in a cool place.




1. ALWAYS KEEP THE MUZZLE POINTED IN A SAFE DIRECTION.

There are several safe "carries" depending on the situation. **NEVER ALLOW THE MUZZLE TO POINT IN THE DIRECTION OF A PERSON.**


2. TREAT EVERY GUN AS IF IT WERE LOADED.

You can never be positive that you were the last person to handle the gun. Never take anyone's word about whether or not a gun is loaded. Always check a gun to see if it is loaded when removed from storage or received from another person. Even if you have fired an airgun one or more times and no pellet or BB was expelled from the barrel, it does not mean that the magazine of the gun is empty of ammunition. Any airgun can fail to feed for any number of reasons. Continue to treat the airgun as loaded and ready to fire. **ALWAYS TREAT A GUN AS IF IT IS LOADED EVEN IF YOU KNOW IT ISN'T.**



3. ONLY LOAD OR COCK A GUN WHEN YOU ARE SHOOTING.


A loaded gun has no place in your home or other public place.



4. CHECK YOUR TARGET AND BEYOND YOUR TARGET.

Be sure all persons are well clear of the target area before you shoot. Check behind and beyond your target to be certain you have a safe backstop and that no person or property could be endangered.





5. ANYONE SHOOTING OR NEAR A SHOOTER SHOULD WEAR SHOOTING GLASSES.

Also, all other persons should remain behind the shooter.

6. NEVER CLIMB OR JUMP WITH A GUN.

You can't control the direction of the muzzle if you stumble or fall. You should safely lay the gun down or hand it to a companion while you climb or jump over anything.

7. AVOID RICOCHET.

Never shoot at a flat hard surface or at the surface of water. Ammunition can ricochet off of water just like a skipped rock.

8. KEEP THE MUZZLE CLEAR.

Never let anything obstruct the muzzle of a gun. Don't allow the muzzle to come in contact with the ground.


9. GUNS NOT IN USE SHOULD ALWAYS BE UNLOADED.

Keeping guns unloaded when not in use is critical to the safety of you and others. When you are finished shooting, put the trigger safety in the "on" position and unload the gun. Store guns so that they are inaccessible to untrained shooters and store ammunition separately from the gun.

10. RESPECT OTHER PEOPLE'S PROPERTY.

Whether you're target shooting or hunting, if you're a guest on others' land, you should leave it exactly as you found it.

11. DON'T DISASSEMBLE OR MODIFY THE GUN



BEDIENUNGSANLEITUNG

⚠ Warnhinweis: Dieses Produkt ist ein Luftgewehr mit hoher Leistung für Benutzer ab 18 Jahre. Es ist kein Werkzeug. Die Benutzung dieses Luftgewehrs entsprechend kontrollieren. Eine willkürliche oder achtungslose Benutzung kann zu ernsthaften Körperverletzungen oder gar zu Tod führen. Es ist wichtig, die Anleitung zu lesen und zu beachten.

⚠ Warnhinweis: Nehmen Sie immer an, dass das Luftgewehr geladen ist und mit ihm jederzeit geschossen werden kann. Stellen Sie immer sicher, dass das Luftgewehr in eine sichere und ungefährliche Richtung gerichtet ist.

WC-321

Explode View

